


## DESIGN & INSTALLATION GUIDE



marleypd.co.uk



## HDPE Soil

Marley HDPE is a drainage system which offers an alternative solution to cast iron. It is particularly suited for commercial applications or where a product with high impact or abrasion resistance is required, such as hospitals, hotels, schools, as well as residential buildings. Marley HDPE is certified to BS EN 1519. HDPE will also cope with temperature variations of -40°C to 100°C \* making it ideal for external as well as internal installations.

\*Applications possible between -40°C and 80°C. HDPE is suitable up to 100°C for short periods of time.





- 4 Range overview
- Product specification
- 18 System overview
- 20 Material properties
- 22 Installation
- 23 HDPE jointing methods
- 32 Transitions to other materials

## INNOVATION & EXPERTISE







## Range overview



The HDPE soil range is certified to BS EN 1519: 2000 (licence number KM 545820). An extension of the Marley soil & waste portfolio, the HDPE range offers an alternative solution to cast iron.

It is particularly suited for commercial applications or where a product with high impact or abrasion resistance is required, such as hospitals, hotels, schools, as well as residential buildings.



#### Key fitting: Stack-aerator

The need for secondary venting in high-rise buildings can be eliminated with the aerator. The unique shape of the HDPE stack-aerator fitting maintains the core of air inside the stack. This keeps the positive and negative pressures within the required limits to prevent trap seal breach, without the requirement of secondary venting. The vent opening between the offset chamber and the entry chamber keeps the horizontal pipe ventilated.

The unique shape of the fitting increases the capacity of the stack allowing the soil and waste flow from the higher floors to smoothly converge with the flow on the lower floor

#### **Features and benefits**

- Light weight
- Easy to handle on site
- High impact and temperature resistant
- Abrasion resistant
- Alternative to cast iron
- Provides quick hygeince removal of sanitary waste water
- Secure joints for medium and high rise buildings
- Compatible with the Marley PVCu soil and waste system for branch connection

#### **Key product information**

- Size range: 56mm, 75mm, 110mm, 160mm, 200mm, 250mm and 315mm
- Other sizes are available. Speak to Customer Services on 01622 852585 for further information.
- Temperature range: -40°C 100°C (short term)

#### **Typical applications**

- Commercial projects
- Student accommodation
- Hotels
- Apartments
- Hospitals



An acoustic soil range with a layered pipe providing quick, hygienic removal of sanitary waste water. The noise generated by the flow of water is dramatically reduced – making it perfect for multi-occupancy apartment blocks and high specification developments.

#### Features and benefits

#### Light weight

- Easy to handle on site
- 16dB at 4 l/s discharge rate, when using 110mm Phonoklip<sup>®</sup> bracket
- Secure push-fit jointing system
- Quick and easy to install
- Provides quick and hygienic removal of sanitary waste water
- Dramatically reduce the sound of waste water
- Compatible with the Marley PVCu soil and
- waste system for branch connection
- High impact and temperature resistant

## PVCu Soil and waste systems

The PVCu soil system is available in 82mm, 110mm and 160mm and the waste system is available in 32mm, 40mm and 50mm sizes. Marley's soil and waste systems have pushfit and solvent weld options incorporating socketed and plain ended pipe.

110mm and 160mm pipe support components have been designed specifically to support horizontal or vertical suspended PVCu pipework.





#### Key product information

- Size Range: 110mm and 160mm
- Temperature Rating: 95°C (Short term)

#### **Typical applications**

Sound attenuated drainage systems in:

- Apartments
- Hotels
- Libraries
- Hospitals
- Public buildings
- Restaurants
- Pushfit or solvent weld jointing options
- Quick and easy installation saving time and money
- All collar bosses are individually pressure tested to ensure joint integrity
- Hole-saw locator on all bosses for ease of installation



PIPE	E LENGTH = 5	M						
d,	Code	e	cm <sup>2</sup>	Qty	d <sub>1</sub> Code	e	cm <sup>2</sup>	Qty
56	S 10 56 00	3.0	19.60	149	200 <b>S 10 20 00</b>	6.2	276.41	20
75	S 10 07 00	3.0	37.40	81	250 <b>S 10 25 00</b>	7.7	431.52	12
110	S 10 11 00	4.2	80.70	75	315 <b>S 10 31 00</b>	9.7	685.35	10
160	S 10 16 00	6.2	171.10	39				

PIPE	E LENGTH = 3	Μ		
d,	Code	e	cm <sup>2</sup>	Qty
110	S 10 11 03	4.2	80.70	48


cm<sup>2</sup> = cross sectional area of flow Pipe = Tempered

#### ELECTROFUSION COUPLER



	d,	Code	D L	System	Qty	Т	d,	Code	D	L	System	Qty
	56	S 41 56 95	68 54	5A/80s	20	Т	200	S 41 20 65	233	175	220V/420s	1
1	75	S 41 07 95	87 54	5A/80s	20		250	S 41 25 65	283	175	220V/420s	1
	110	S 41 11 95	123 60	5A/80s	20		315	S 41 31 65	349	175	220V/420s	1
ŕ	160	S 41 16 95	172 66	5A/80s	5							

#### EXPANSION SOCKET



		Тур	e B						
D d L	Qty	d,	Code		D	d	L	Ι,	Qty
* 100 76 256	20	56	S 40 56 20	*	74	57	172	135	20
* 137 112 256	20	200	S 40 20 20	**	230	202	310	245	1
* 189 162 265	5	250	S 40 25 20	**	300	253	330	265	1
		315	S 40 31 20	**	370	319	360	290	1

Seals: SBR \* Includes protection plug \*\* Excludes protection plug / Butt-weld only See page 30 for details on TYPE A / TYPE B

Туре А d<sub>1</sub> Code

75 S 42 07 20 110 S 42 11 20 160 **S 42 16 20** 

#### PLUG-IN SOCKET




d,	Code	D	d	L	Ι,	Qty		d,	Code		D	d	L	Ι,	Qty
56/3	2 <b>S 42 32 50</b>	56	?	77	38		Τ	75	S 42 07 50		96	76	109	69	20
56/4	0 <b>S 42 40 50</b>	56	?	75	36			110	S 42 11 50		128	119	101	60	20
56	S 42 56 50	72	57	89	54	20		160	S 42 16 50	*	190	162	151	105	10
Electrofusable spigot ends Seals: SBR Includes protection plug * Butt-weld only															


#### SOCKET REDUCER

Size mm	Code	Α	В	Colour	
56-32	KR310H	32	28	W	R
56-40	KR320H	32	28	W B	
	igot/socket th the plug-in socket S 42 56	50			












#### BEND 90° - LONG









١,

## Additional sizes are available.

#### 6 MARLEY HDPE

Qty 40

40



DL	Qty	d,	Code	D	L	Qty
81 74	20	110	S 66 11 40	145	106	10
111 106	20					

r	Qty	d <sub>1</sub> Code	I,	r	Qty
160	10	250 <b>S 11 25 91</b>	290	265	1
200	10	315 <b>S 11 31 91</b>	340	300	1

I,	$I_2$	r	k,	Qty	d,	Code	I,	$I_2$	r	k,	Qty
120	59	56	55	20	110	S 11 11 96	180	113	110	60	20
140	78	75	60	25							

r k <sub>1</sub>	Qty	d <sub>1</sub> Code	I,	r k <sub>1</sub>	Qty
165 65	1	250 <b>S 18 25 15</b>	225	375 135	1
240 100	1	315 <b>S 18 31 15</b>	250	473 175	1
300 125	1				

For further information, contact our Customer Services department on 01622 852585

BEND 30°




d,	Code	I,	r	k,	Qty	d,	Code	I,	r	k,	Qty
110	S 18 11 30	125	165	60	1	250	S 18 25 30	225	255	125	1
160	S 18 16 30	175	2401	100	1	315	S 18 31 30	250	320	135	1
200	S 18 20 30	200	2001	115	1						
Fabrio	cated										

#### ELBOW 88.5°



 d,	Code	Ι,	k,	Qty	d,	Code	I,	k,	Qty
 56	S 12 56 88	65	20	20	200	S 12 20 8	<b>8*</b> 290	60	1
75	S 12 07 88	75	20	20	250	S 12 25 8	<b>8*</b> 350	60	1
- 110	<b>S 12 11 88</b>	95	25	20	315	S 12 31 8	<b>8*</b> 360	60	1
160	<b>S 12 16 88</b>	120	25	10					
* Fa	bricated								

#### BRANCH 45°



d <sub>1/</sub> d <sub>2</sub>	Code		L	$I_1/I_2$	I <sub>3</sub>	k,	k2	k3	Qty
56/56	S 30 56 56		180	120	60	25	25	40	20
75/56	S 30 07 56		210	140	70	35	25	55	20
75/75	S 30 07 07		210	140	70	25	25	40	20
110/56	S 30 11 56		270	180	90	45	40	90	10
110/75	S 30 11 07		270	180	90	35	30	75	10
110/110	S 30 11 11		270	180	90	20	20	55	15
160/56	S 30 16 56	*	375	250	125	120	115	65	5
160/75	S 30 16 07		375	250	125	120	115	65	5
160/110	S 30 16 11		375	250	125	50	40	45	5
160/160	S 30 16 16		375	250	125	10	15	25	5
200/75	S 30 20 07		540	360	180	95	160	175	1
200/110	S 30 20 11		540	360	180	65	140	150	1

#### ELBOW 45° - SHORT



	d,	Code	I <sub>1</sub>	k,	Qty	d,	Code	I,	k <sub>1</sub>	Qty
	56	S 12 56 45	45	20	20	200	S 12 20 45	173	60	5
	75	S 12 07 45	50	20	20	250	S 12 25 45	182	60	5
$\langle \mathcal{N} \rangle$	110	S 12 11 45	60	25	20	315	S 12 31 45	195	60	5
	160	S 12 16 45	69	20	5					


BRANCH 88.5°

d <sub>1/</sub> d <sub>2</sub>	Code		L	$I_1/I_2$	I <sub>3</sub>	k,	k2	k3	Qty
56/56	S 20 56 56		175	70	105	30	30	65	20
75/56	S 20 07 56		175	70	105	30	25	65	20
75/75	S 20 07 07		175	70	105	25	25	55	20
110/56	S 20 11 56		225	90	135	45	25	90	10
110/75	S 20 11 07		225	90	135	35	25	85	10
110/110	S 20 11 11		225	90	135	20	20	65	15
160/56	S 20 16 56	*	350	140	210	75	30	145	5
160/75	S 20 16 07	*	350	140	210	80	45	150	5
160/110	S 20 16 11		350	140	210	60	45	135	5
160/160	S 20 16 16		350	140	210	30	35	105	5
200/75	S 20 20 07	*	360	180	180	90	60	90	1
200/110	S 20 20 11	*	360	180	180	70	60	70	1

#### ELBOW 45° - LONG



d,	Code	I <sub>1</sub> I <sub>2</sub>	Qty	
75	S 12 07 46	145 50	20	
110	S 12 11 46	155 60	20	
from 1 sta	stack to building	1.5 11	ed for making the transition 12056 (see drawing).	2 x S 12 07 S 12 11



Additional sizes are available.

For further information, contact our Customer Services department on 01622 852585

8 MARLEY HDPE



d <sub>1/</sub> d <sub>2</sub>	Code		L	$I_1/I_2$	$I_3$	k,	k2	k3	Qty
200/160	S 30 20 16		540	360	180	35	85	115	1
200/200	S 30 20 20		700	430	270	160	160	230	1
250/110	S 30 25 11	*	660	440	220	150	185	215	1
250/160	S 30 25 16	*	660	440	220	120	130	180	1
250/200	S 30 25 20	*	660	440	220	90	50	150	1
250/250	S 30 25 25	*	900	600	300	160	160	250	1
315/110	S 30 31 11	*	840	560	280	235	260	305	1
315/160	S 30 31 16	*	840	560	280	200	205	270	1
315/200	S 30 31 20	*	840	560	280	175	125	240	1
315/250	S 30 31 25	*	840	560	280	140	130	205	1
315/315	S 30 31 31	*	950	610	340	170	170	280	1


\* Fabricated

d <sub>1/</sub> d <sub>2</sub>	Code		L	$I_1/I_2$	I <sub>3</sub>	k,	k <sub>2</sub>	k3	Qty
200/160	S 20 20 16	*	360	180	180	45	60	45	1
200/200	S 20 20 20	*	360	180	180	25	60	25	1
250/110	S 20 25 11	*	440	220	220	110	70	110	1
250/160	S 20 25 16	*	440	220	220	85	70	85	1
250/200	S 20 25 20	*	480	240	240	65	40	65	1
250/250	S 20 25 25	*	480	240	240	40	40	40	1
315/110	S 20 31 11	*	560	280	280	170	90	170	1
315/160	S 20 31 16	*	560	280	280	145	90	145	1
315/200	S 20 31 20	*	560	280	280	120	65	120	1
315/250	S 20 31 25	*	560	280	280	95	65	95	1
315/315	S 20 31 31	*	560	280	280	70	65	70	1

\* Fabricated

Equal branches for rainwater applications only

#### DOUBLE BRANCH 45°



$d_{1/}d_{2}$	Code	L	Ι,	$I_2$	k,	k <sub>2</sub>	k3	
110/110	S 36 11 11	270	180	100	65	20	20	

Qty 10

Qty

15

Code

110/110 **S 25 11 11** 

 $d_{1/} d_{2}$ 


#### **DOUBLE BRANCH 60°**



d <sub>1/</sub> d <sub>2</sub>	Code	I,	l <sub>2</sub>	Qty
110/110	S 37 11 11	90	102	5

#### BRANCH 88.5° – SWEPT ENTRY






L I<sub>1</sub> I<sub>2</sub> k<sub>1</sub> k<sub>3</sub>

225 135 130 30 30

#### BRANCH 45° - CLEAN OUT





$d_{1/}^{}d_{2}^{}$	Code	D	L	I,	I2	I <sub>3</sub>	k,	k3	Qty
110/110	S 33 11 00	140	270	180	195	90	20	55	1
160/110	S 33 16 00	140	375	250	220	125	45	45	1

#### **BRANCH 90°- CLEAN OUT**



-d <sub>1</sub>	$d_{1/}d_{2}$	Code
	56/56	S 23 56 00
	75/75	S 23 07 00
s k L L	110/110	S 23 11 20
	160/110	S 23 16 20
	200/110	S 23 20 00
	250/110	S 23 25 00
	315/110	S 23 31 00
12		

$d_{1/}d_{2}$	Code	D	L	I,	$I_2$	$I_3$	k,	k3	Qty
56/56	S 23 56 00	83	175	70	100	105	30	65	1
75/75	S 23 07 00	91	175	70	100	105	25	55	1
110/110	S 23 11 20	127	225	90	105	135	20	65	1
160/110	S 23 16 20	140	350	140	140	210	60	135	1
200/110	S 23 20 00	140	360	180	160	180	90	90	1
250/110	S 23 25 00	140	440	220	185	220	110	110	1
315/110	S 23 31 00	140	560	280	220	280	170	170	1


## Additional sizes are available.

For further information, contact our Customer Services department on 01622 852585

#### BALL BRANCHES

	1 DOUBLE	2 DOUBLE	3 DOUBLE		5 TRIPLE	6 FOURFOLD							
	90°	135°	180°	90°	135°	90°							
$d_1/d_2$	Code	Code	Code	Code	Code	Code	L	$I_1$	$I_2$	D	k,	k <sub>2</sub>	Qty
110/56	S 24 11 15	S 24 11 25	S 24 11 35	S 34 11 15	S 34 11 25	S 44 11 15	275	135	140	170	30	15	1
110/75	S 24 11 17	S 24 11 27	S 24 11 37	S 34 11 17	S 34 11 27	S 44 11 17	275	135	140	170	30	15	1
110/110	S 24 11 01	S 24 11 02	S 24 11 03	S 34 11 01	S 34 11 02	S 44 11 01	275	135	140	170	30	30	1

#### GENERAL DIMENSIONS







5 TRIPLE BALL BRANCH 88.5° FABRICATED - 135°







#### FOUR WAY RISER



FOUR WAY SOIL MANIFOLD

	a <sub>1/</sub> a <sub>2</sub>	C
	110/56	4
-d <sub>2</sub> -	4 x 56mr 1 x 110m 1 x 110m	nm to

d <sub>1/</sub> d <sub>2</sub>	Code	L I,	Qty					
10/56	46 11 11	232 144	1					
x 56mm side inlets electrofusable (factory closed)								

 $\mathsf{L} \quad \mathsf{L}_1 \quad \mathsf{L}_2 \quad \mathsf{L}_3 \quad \mathsf{L}_4 \quad \mathsf{k}_1 \quad \mathsf{k}_2$ 

275 162 134 85 136 30 70

top inlet electrofusable ottom outlet electrofusable

Code

S 44 11 56

 $d_{1/} d_{2}$ 

110/56

END CAP - DOMED




**56MM BOSS ADAPTER** 


**REDUCER ECCENTRIC - LONG** 








#### **REDUCER ECCENTRIC - SHORT**






#### **REDUCER CONCENTRIC**



## END CAP - FLAT




d,	Code	D	L	I,	Qt
56	S 67 56 07	64	16	12	20
75	S 67 07 07	85	21	16	20
110	S 67 11 07	120	19	19	20
Butt-we	d only				

Additional sizes are available.

## For further information, contact our Customer Services department on 01622 852585

## STACK-AERATOR



d,	Code		L	I,	$I_2$	I <sub>3</sub>	$I_4$	$I_{5}$	I <sub>6</sub>	١,	$I_8$	I <sub>9</sub>	Qt
110	S 60 1	1 17 *	705	295	170	240	60	279	89	178	55	130	1
160	S 60 1	6 17 *	750	330	170	250	60	339	114	228	80	140	1
							_						

\* 1/2/3 = max. Ø 110 mm – 4/5/6 = max. Ø 75 mm Butt-weld - hand-held hot plate recommended. See page 29 for further details.

Qty

Qty

1



d,	Code	L	Qty
160	S 67 16 09	45	1
200	S 67 20 09	55	1
250	S 67 25 09	30	1
315	S 67 31 09	30	1

Butt-weld only

d,	Code	Qty
32	S 00 56 32	
40	S 00 56 40	

Material: TPE

d,	Code		L	Ι,	I <sub>2</sub>	I <sub>3</sub>	$I_4$	$d_{_3}$	k,	k22	Qty
200/110	S 14 20 11	*	335	95	36	165	55	160	75	20	1
200/160	S 14 20 16	**	260	95	95				75	75	1
250/200	S 14 25 20	**	290	105	95				85	75	1
315/200	S 14 31 20	*	580	115	95	235	190	250	95	75	1
315/250	S 14 31 25	**	340	115	105				75	85	1
' type A											


type F

d1/d2	Code	I,	$I_2$	Qty
75/56	S 16 07 56	35	37	20
110/40	S 16 11 04	31	34	10
110/56	S 16 11 56	31	35	10
110/75	S 16 11 07	31	36	20
160/110	S 16 16 11	28	36	5

d,	Code	Ι,	I2	Qty
75/56	S 15 07 56	30	30	20
110/40	S 15 11 04	30	30	20
110/56	S 15 11 56	30	30	20
110/75	S 15 11 07	30	30	20
160/110	S 15 16 11	35	30	1
200/160	S 15 20 16*	50	40	20
250/160	S 15 25 16*	60	40	20
250/200	S 15 25 20*	60	50	20
315/200	S 15 31 20*	90	80	20
315/250	S 15 31 25*	90	90	20

\*Butt-weld only


#### CONTRACTION SLEEVE



d,	Code	L	I,	d <sub>x</sub>	Qty
50/70	S 55 05 03	210	65	57-64	5
56/75	S 55 56 01	210	70	62-69	5
75/90	S 55 07 01	210	75	80-84	5
110/125	S 55 11 02	210	100	102-111	5
Seal: NBR					

For jointing HDPE to concrete / clayware / copper / stainless steel

#### DOUBLE WC CONNECTOR 90° - VERTICAL



**DOUBLE WC CONNECTOR 90° - HORIZONTAL** 

#### STUB FLANGE



d,	Code		d <sub>2</sub>	D	L	Ι,	k,	Qty
56	S 47 56 02	*	70	102	60	14	15	5
75	S 47 07 02	*	89	120	50	16	15	5
110	S 47 11 02		125	158	80	18	30	5
160	S 47 16 02		175	210	80	18	30	1
200	S 47 20 02	*	232	268	100	18	40	1
250	S 47 25 02	*	285	320	100	20	40	1
315	S 47 31 02	*	335	370	100	20	40	1

#### \* Butt-weld only

#### WC CONNECTOR 90°




WC CONNECTOR 90° - HORIZONTAL

d <sub>1</sub> /d	Code		I,	$I_2$	I <sub>3</sub>	$I_4$	$I_5$	k,
110/90	S 50 11 85	*	225	76	34	95	17	120
110/110	S 50 11 82	**	225	75	30	92	19	120
* Seal: SBR ** Seal: NBR Includes pro	t otection plug							

**Qty** 10 10


**Qty** 5 5

## WC CONNECTOR SOCKET



HDPE pipe and fittings available in black, with the exception of protection plug (white)







Left						
d <sub>1</sub> /d	Code		Ι,	$I_2$	$I_3$	k,
110/90	S 50 10 32	*	350	100	75	170
110/110	S 50 11 32	**	350	100	75	170
Seal: SBR						

Includes protection plug


#### Right

d <sub>1</sub> /d	Code		Ι,	$I_2$	$I_3$	k,	Qty
110/90	S 50 10 33	*	350	100	75	170	5
110/110	S 50 11 33	**	350	100	75	170	5

\* Seal: SBR \*\* Seal: NBR Includes protection plug

Additional sizes are available.

### For further information, contact our Customer Services department on **01622 852585**







d,/d	Code	l <sub>1</sub> l <sub>2</sub> k <sub>2</sub>	Qty
110/110	S 50 11 34	185 270 60	5

Seal: NBR Includes protection plug

d <sub>1</sub> /d	Code		$I_2$	I,	k,	Qty
110/90	S 50 09 35	*	100	275	200	1
110/110	S 50 11 35	**	100	270	200	1

\* Seal: EPDM

\*\* Seal: NBR

Includes protection plug

d,	Code		d	D	L	I,	Qty
90	S 50 09 51	*	90	113	49	38	10
110	S 50 11 71	**	110	130	45	28	10
* Seal: SBR							

\*\* Seal: NBR

## Case study Crayford Town hall

The conversion of this very large masonry structure – originally built as part of the Vickers Armaments Factory in 1915. All of the plumbing and drainage work has been undertaken by specialist sub-contractor, Maybrick: including the installation of the Marley HDPE system, suspended beneath the soffit of the basement car park which extends across most of the building's footprint.

#### BRACKET-ANCHOR



d,	Code	а	b	s	R	Qty
56	S 70 56 78	113	30	2.5	"1⁄2"	1
75	S 70 07 78	126	30	2.5	"1⁄2"	1
110	S 70 11 78	161	30	2.5	"1⁄2"	1
160	S 70 16 78	215	30	2.5	"1⁄2"	1
200	S 70 20 80	283	40	4	"1"	1
250	S 70 25 80	333	40	4	"1"	1
315	S 70 31 80	398	40	4	"1"	1

Galvanised steel

P	PF	SC	RA	PF	I

PIPE SCRAPER		
A	Code	Qty
Contraction of the second seco	S 41 96 00	1
SPIDER SCRAPER	Code	Qty
Q	S 41 98 65	1
主义	With metal lever	1
PIDER SCRAPER SPARE BLADES		
	Code S 41 98 61	<b>Qty</b>
PIPE CUTTER		
	Size Code	Qty
	40-63mm <b>\$ 49 09 10</b>	1
	50-125mm <b>\$ 49 10 10</b>	1
	110-160mm <b>S 49 11 10</b>	1
E CLEANER	Code	
	Code S 60 10 00	Qty 1
GREASE PENCIL		
	Code	Qty
	S 41 96 20	1
PROTECTION FOR PLUG-IN SOCKET		
	d, Code	Qty
	56 <b>S 40 56 19</b> 75 <b>S 40 07 19</b>	1
	110 <b>S 40 07 19</b>	1
	160 <b>S 40 16 19</b>	1
	200 <b>S 40 20 19</b>	1
	Fits on the inside of a plug in socket	
PROTECTION CAP FOR PIPE END		
- P - 5	d, Code D L	Qty
	56 <b>S 40 56 29</b> 58 35	1

#### BRACKET-GUIDE



70 56 10	113					
	115	30	2.5	M10		1
70 07 10	126	30	2.5	M10		1
70 11 10	161	30	2.5	M10		1
70 16 10	215	30	2.5	M10		1
	0 11 10	<b>0 11 10</b> 161	<b>0 11 10</b> 161 30	<b>0 11 10</b> 161 30 2.5	0 0 7 10 126 30 2.5 M10   0 11 10 161 30 2.5 M10   0 16 10 215 30 2.5 M10	<b>0 11 10</b> 161 30 2.5 M10


Galvanised steel

#### CLAMP LINERS



d,	Code	L	Ι,	s	Qty
56	S 70 56 15	40	30	1	1
75	S 70 07 15	40	30	1	1
110	S 70 11 15	40	30	1	1
160	S 70 16 15	40	30	1	1
200	S 70 20 15	50	38	1	1

#### MOUNTING PLATE



Code		R	I,	I2	I <sub>3</sub>	$I_4$	S	с	Qty
S 70 94 78	*	1⁄2"	145	38	90	25	4	8,5	1
S 70 94 10	**	M10	145	38	90	14	4	8,5	1
S 70 94 80	**	1"	145	38	90	25	4	8,5	1

Galvanised steel





Code	D	L		Qty
S 40 56 29	58	35		1
S 40 07 29	78	35		1
S 40 11 29	113	40		1
S 40 16 29	164	40		1
	S 40 56 29 S 40 07 29 S 40 11 29	S 40 56 29 58   S 40 07 29 78   S 40 11 29 113	Code D L   S 40 56 29 58 35   S 40 07 29 78 35   S 40 11 29 113 40   S 40 16 29 164 40	S 40 56 29 58 35   S 40 07 29 78 35   S 40 11 29 113 40

## System Overview

HDPE Soil is a durable and tough drainage system, designed to be installed in accordance with EN12056 'Gravity drainage systems inside buildings'.

The excellent characteristics of high density polyethylene (HDPE) makes it suitable for a wide range of applications. HDPE is available in various pipe sizes, with a comprehensive range of fittings including connection fittings, sanitary fittings and tools.

#### The system has the following features:

- Complete system with excellent mechanical and chemical resistance properties
- Manufactured from polyethylene: a proven material that is tough, elastic and flexible
- HDPE pipe is tempered for reduced stress on connections
- Homogenous welded joints offer a completely closed system
- A wide range of mechanical joints for adjustability, flexibility and demounting
- Additives makes HDPE UV and weather resistant
- HDPE is highly suited for prefabrication
- Non-toxic plastic, 100% recyclable and environmentally friendly
- Stack-aerator is the perfect high-rise solution

#### **Applications**

HDPE is designed to be installed in accordance with EN 12056 and thereby meets the requirements for use in residential, commercial and public buildings.

HDPE is a non-pressure drainage system, not intended for pressure applications.

HDPE has a high temperature and chemical resistance which makes it ideal for drainage in:

- Student accommodation
- Apartments
- Commercial projects
- It is flexible and tough for installation:
- Underground
- Embedded in concrete

Its closed system is perfect for applications where system integrity connections are critical like in:

- Industrial applications
- Ceiling voids and hard to reach places

Furthermore HDPE is a light weight system, highly suited for prefabrication. It allows you to meet the challenges of modern building design.

#### Application parameters

The pipes, fittings and seals can be used continuously at elevated temperature.

For a complete overview refer to the appendix on page 52. HDPE is suitable for the drainage of chemically aggressive waste water with a pH value of 2 (acidic) to 12 (basic) by default. For installations in applications not listed in this brochure or with chemicals not listed in the chemical resistance list of this brochure, please contact Technical Services on 01622 852695

Behaviour in fire corresponds to B2 normal combustibility according to DIN 4102. When a HDPE pipe system passes through fire-rated building elements, it is mandatory to install fire protection collars that will not reduce the fire-rating of these building elements.

#### **Tempered Pipe**

Marley HDPE pipe is tempered. This pipe is produced according to the standards EN 1519 and ISO 8770 and has undergone a heat treatment after extrusion. The result is less shrinkage when cooled down from high operational temperature. This gives less stress on joints resulting in a longer life for the pipe system.

The tempered pipes are suited for applications where the temperature of the pipe can get relatively high or vary considerably. Both can be caused by ambient temperature or temperature of the medium.

#### Linear expansion

Marley HDPE material has a linear expansion coefficient of 0.18 mm/mK. We calculate with an expansion of 0.2mm per meter pipe for every °C temperature difference. The total length variation can be calculated as follows:

- $\Delta I = L x \lambda x \Delta t$
- $\Delta I = \text{length change in mm}$
- L = total length of pipe
- $\lambda$  = linear expansion coefficient
- Δt = temperature difference in °C

#### 10 metres of pipe with a maximum temperature of 60°C and a minimum temperature of -20°C. This results in an expansion of:

Example:

 $\Delta I = 10 \times 0.2 \times 80 = 160 \text{ mm}$ 

Length changes can be accommodated by the expansion socket which can take up the expansion and contraction of a 5 meter length of pipe for temperatures between -20°C and 70°C.

#### Fittings

Bends

HDPE fittings are high quality injection moulded products produced under ISO9001 quality management. Prefabricated product exceptions are clearly listed in the product tables. Marley offers a complete wide range of fittings including:


- Reducers
  - Electrofusion
- couplers Elbows
- Branches

Fixing materials for wall and ceiling construction are also available.

stated

In some situations, it is necessary to shorten fittings. Fittings with the dimension "k" included in the product table can be maximally shortened by the "k" dimension in order to still allow buttwelding using a standard butt-welding machine. The k-dimension of the relevant spigot of most fittings is listed in the product tables.





• End caps

Sanitary fittings



#### **Abbreviations**

Abbreviation		
D	External dimension fitting part	
d1, d2	External dimension fitting/pipe	
e	Wall thickness	
k1,k2	Maximum length for shortening fittings	
L	Total length fitting	
l <sub>1</sub> ,l <sub>2</sub>	Lengths of part of fitting	
TPE	Thermoplastic Elastomer	
SBR	Styrol butadiene rubber	
NBR	Acrylnitril-butadiene rubber	
HDPE	High density polethylene	
SDR	Ratio diameter / wall thickness d,/e	

All HDPE fittings are electrofusable, unless

The fittings are dimensionally standardised to improve prefabrication repetition work and to facilitate welding alignment. Each fitting contains a graduated arc at 15° intervals.

#### Tools

Marley offer a range of tools to be used for installation of HDPE:

- Pipe cutters
- Pipe and fitting scrapers
- PE cleaner and marking pencils

Refer to page 17 for further details.

## **Material Properties**

#### **HDPE** properties

Polyethylene (PE), is a semi crystalline thermoplastic and is a generic term for different kinds of PE. By colouring with 2% of 'carbon black' the PE gets its black colour. The following kinds of PE are generally used:

- LDPE (Density 0.90-0.91 g/cm<sup>3</sup>)
- MDPE (Density 0.93-0.94 g/cm<sup>3</sup>)
- HDPE (Density 0.94-0.97 g/cm<sup>3</sup>)

In pipe systems generally only HDPE is used. HDPE has a high resistance against acids, bases and aqueous salt-solutions. Below 60°C it is practically unsolvable in organic solutions. HDPE has a good resistance against light ionised radiation without becoming radioactive itself.

#### Technical specifications

	Unit	Test method	Value
Density at 23°C	g/cm <sup>3</sup>	ISO 1183	0.954
Elasticity modulus	N/mm <sup>2</sup>	ISO 527	850
Bending creep modulus	N/mm <sup>2</sup>	DIN 54852-Z4	1000
Tensile strength at 23°C	N/mm <sup>2</sup>	ISO 527	22
Elongation at break	%	ISO R 527	300
Linear expansion coefficient	mm/mK	DIN 53752	0.18
Indentation hardness	N/mm <sup>2</sup>	ISO 2039	36 - 46
Ignition temperature	°C	-	~350
Thermal conductivity	W/m . K	DIN 52612	0.37 - 0.43
Shore hardness		ISO 868	61
Crystallite melting range	°C		125 - 131
Operational temperature range	°C	-	-40 - +80*
Melt Flow Rate MFR 190/5	g/10 min	ISO 1133	0.43

\* up to 100°C for short periods of time.

#### Ecological properties of HDPE

Polyethylene consists of only carbon and hydrogen atoms. These substances are not harmful to humans, animals and plants. Marley uses High Density Polyethylene classified with recycle mark 3.



Polyethylene is made from oil and electricity without chemical additives released during production. It is not broken down by bacteria very fast and has a long lifetime. The total energy consumption during production and transport is very low compared to steel, copper or cast iron.

Because PE is a thermoplastic polymer it can be melted at the end of its technical lifetime and used for other applications. When PE is burnt, only non-toxic carbon dioxide and water is released.

#### Chemical resistance

When transporting chemical waste waters the following factors have to be taken into account:

- The medium
- The concentration of this medium
- Temperature
- Duration of exposure
- Volume

Refer to appendix A for a complete chemical resistance table of Marley HDPE on page 52.

#### Trace heating

Animal and vegetable-based oil and grease discharged by commercial kitchens are separated from the waste water by grease separators. HDPE is very well suited to connect the discharge fixtures to the grease separator. When the pipe system has enough length, the grease can accumulate and lead to serious blockage of the pipe system. The use of trace heating and additional insulation may be required to reduce heat loss. The trace heating element should not exceed 45°C.

#### Embedding HDPE in concrete

The HDPE system is suited to be embedded in concrete. Before pouring the concrete all welds need to be cooled down and it is preferable to check the pipe system for leakage. To prevent the pipes from floating upwards the systems needs to be properly bracketed to keep it in place.

#### Quick drying concrete

Quick drying concrete will undergo an exothermic reaction which releases heat during its process. The heat will soften the HDPE pipe and influence the maximum allowed pressure. Adequate protection must be provided to the HDPE system like filling the system with water. For further information on embedding HDPE in concrete see page 43.

## Pressure and heat during concrete pouring

When a pipe system is vertically installed into concrete the liquid concrete will cause outer pressure, possibly exceeding the maximum ring stiffness depending on the height of the installation.

To increase the maximum installation height the pipe can be filled with water (and closed) to compensate for the outer pressure. Refer to the table opposite for the maximum allowed height depending also on the wall thickness of the pipes and fittings (at 30°C).

#### Diameter (mm) 40 50 56 63 75 90 110 125 160 200 250 315 200 250

315

#### Thermal movement of HDPE

A physical principal is that all materials expand as the temperature increases. If the temperature drops, the material contracts. Each material has its own unique coefficient of expansion ( $\alpha$ ).

For HDPE :  $\alpha$  = 0,18 mm/m • K The formula for length change is:

#### $\Delta \mathbf{L} = \mathbf{L} \mathbf{x} \boldsymbol{\alpha} \mathbf{x} \Delta \mathbf{T}$

- $\Delta L$  = length change of pipe system [mm]
- L = total pipe length [m]
- $\Delta T$  = difference with installation
- temperature [°C]
- α = 0,18 mm/m °K

∆T 50° = 10 mm/m


In residential applications the maximum wall temperature difference of the connector and collector pipes is 40°C, even during short periods of 80°C to 90°C temperature water discharge. For downpipes and ground pipes the maximum wall temperature difference is 20°C.

In general for a long-lasting discharge of high volume hot water the maximum wall temperature difference is 60°C.



Wall thickness (mm)	Allowed height (m)		
	Empty	Filled with water	
3.0	26.0	45.0	
3.0	14.0	24.0	
3.0	7.0	12.0	
3.0	7.0	12.0	
3.0	3.8	6.5	
3.5	3.8	6.5	
4.2	3.8	6.5	
4.8	3.8	6.5	
6.2	3.8	6.5	
6.2	2.0	3.5	
7.7	2.0	3.5	
9.7	2.0	3.5	
7.7	3.8	6.5	
9.6	3.8	6.5	
12.1	3.8	6.5	

When installed at 30° a Marley HDPE pipe of 5m long will behave as follows:



Please note that this is the temperature difference over the complete circumference of the pipe, the variation in the discharge temperature can be a lot higher.

## Installation

# HDPE jointing methods

#### Installation underground

Due to specific properties such as flexibility and resistance to cold temperature (freezing), HDPE pipe systems are ideal for use in underground pipe lines. Buried pipes are exposed to various loads. The stability of HDPE makes it possible to bury the pipes at substantial depth. The suitability depends on such factors as depth, groundwater level, density of the soil and traffic load. For further information on installing HDPE underground see page 44.

#### Soil and traffic loads

The load capacity of underground plastic pipes is based on changes in the pipe and movement of the ground. The soil load causes the top of the pipe to deflect downward. The sides of pipe are correspondingly pressed outward against the surrounding soil. The reaction pressure, the lateral force exercised on the pipe, prevents a larger cross-sectional deformation (support function). The construction of the trench, the type of bedding used and the backfilling of the trench are, to a large extent, decisive factors determining the load capacity of an underground plastic pipe. The load needs to be evenly distributed over the entire pipe line. For this reason, the trench must be created in such a manner that bends in a longitudinal direction and loads at specific points are avoided. It is assumed that the increased pressure resulting from traffic loads caused by road or rail traffic are surface evenly distributed over the pipe sectional plane.

#### Groundwater

Underground pipes can be subject to external overpressure, especially in areas with high groundwater levels. In addition, a pipe enclosed in concrete is exposed to external pressure, though just for a short period. Underground pipe systems subject to additional external pressure must be tested for the ability to withstand dinting. The effective load due to external pressure will agree with the related hydrostatic pressure on the pipe axis.

For special circumstances contact our Technical Service department on 01622 852695.

HDPE fittings and pipes can be joined by different methods. Joints are divided in welded/mechanical and pull-tight/not pull-tight. Pull-tight joints can't come apart under influence of external forces.

#### To be opened (demountable)

These are jointing methods which can be disconnected after assembly. These jointing methods are ideal for pipe sections which need to be cleaned, calibrated, inspected or dismantled on a regular basis.


#### Not to be opened (fixed)

These are jointing methods which cannot be disconnected after assembly. These are permanent joints in which the joints can remain closed for their lifetime.

#### Tension-resistant (pull tight: PT) These are connections which withstand

tensional forces. This is ideal when thermal movement is expected or gravity pulls on the connection.





#### 22 MARLEY HDPE



#### Non-tension-resistant (not pull tight: NPT)

These are connections which cannot withstand tensional forces. This joint is used when the pipe system is designed to accommodate movement without risk that the joint is pulled apart.

echanical	Pull-tight	Demountable
	Yes	No
	Yes	No
	No	Yes
	No	Yes
	Yes	No
	Yes	Yes
	Yes	Yes
	No	No

#### Electrofusion

Electrofusion is a rapid and simple way of permanent jointing. Using the electrofusion couplers and equipment, pipes, fittings and prefabricated pipe sections can efficiently be assembled. All HDPE products can be welded by electrofusion unless specifically stated in the product table, see pages 6-17.



#### **Electrofusion couplers**

Couplers are extremely suitable for applications in wastewater and rainwater drainage, with the following features:

- 1. Injection moulded with excellent dimensional accuracy and stability.
- 2. Welding indicators on each welding surface for visual identification to show that the coupler has been welded.
- 3. Centre stops are easy to remove, in order to use the coupler as a slip coupler.
- 4. Resistance wires fixed to the surface for an optimal heat transfer and therefore a high quality welding connection.
- 5. Yellow edge surrounding the welding indicators of the diameters 200, 250 and 315mm are provided for better visibility.

The resistance wires are positioned in the fusion zone. On both sides of a fusion zone, a cold zone prevents the molten HDPE from outpouring thereby containing the fusion process.

#### Correct Jointing procedure


#### **1.** Cut the pipe square

The pipe ends must be cut square to ensure that the heating element in the coupler is completely covered by the pipe or fitting.



#### 2. Mark insertion depth + 10 mm

This is to ensure that across the full welding zone the oxidised layer will be removed.



During the fusion process the pipe/fitting expands and touches the inner coupler wall. The electrofusion joint is made with the pressure caused by the expanding HDPE and the heat from the resistance wires.

Electrofusion coupler with fusion and cold zones



Without removing the oxygen layer a weld cannot be guaranteed.

3. Scrape pipe and mark insertion

The outer surface of the pipe (approx.

0.2mm deep) must be scraped for

the full distance that will be covered by the coupler to remove any surface

The insertion depth should be marked

again to safeguard full insertion.

depth again

'oxidation'.

#### Preparations

The following guidelines are of importance when making an accurate electrofusion joint:

- Establish a work space where the welding can be done without being effected by major weather conditions. Temperature -10°C/+40°C.
- Check if the equipment functions properly. Welding equipment used on site deserves special attention.
- The resistance wire in the electrofusion coupler lies at the surface for a good heat exchange. The resistance wires need to be covered by the inserted pipe or fitting to ensure correct operation.
- Complete insertion is essential to utilise the fusion and cold zones in the coupler.
- Make sure both ends inserted into the coupler have been properly scraped and have been cleaned. Both pipes and fittings need removal of the oxidation layer.

#### 4. Clean coupler

Before assembling the pipes into the coupler ensure that all surfaces are clean and dry.



5. Insert pipe and/or fitting up to pipe stop

Ensure that the pipe is pushed as straight as possible into the fitting.

	←

#### Welding process

After connecting the cables of the control box the welding process can commence by pushing the start button. The control box adapts the welding time to the ambient temperature. When it is colder than 20°C the welding time is extended and when the ambient temperature exceeds 20°C the welding time is shortened. For welding times and cooling down times see table below.

dimension d <sub>1</sub> mm	system	weld time sec	cooling time min	
40-160	Constant current 5A	80	20	
200-315	Constant voltage 220V	420	30	

The joint assembly should not be disturbed during the fusion cycle and for the specified cooling time afterwards. A full load can only be applied after the complete cooling time. The cooling period can be reduced by 50% when there is no additional load or strain during cooling.




Compared to a butt-weld, it is harder to judge a good electrofusion weld. The welding indicators on the electrofusion coupler provide an indication if the weld has actually been executed. However, they do not guarantee the integrity of the joint. The amount of movement of the pop-out depends on several factors including the size tolerances of the components and any ovality of the pipe or fitting. A joint can be marked o.k. when the

welding indicators are protuded, all welding preparations such as marking insertion depth, scraping making sure that there was no additional load during welding and cooling have been executed successfully. If a significant quantity of melt flows out from the fitting after welding, there may be a misalignment of the components, the tolerances may be excessive or a second welding may have


#### Incorrect Jointing procedure

#### 1. Misalignment





Coupler sliding when installed vertical





accidentally occurred. The integrity of such a joint is suspicious.

Please note that the fitting will become too hot to be touched during the welding process. The temperature will continue to increase for some time after the fusion process has been completed.

#### Deformation


A big deformation of pipe and fitting can cause problems during assembly and welding of the components. The maximum allowed deformation of pipe or fitting spigot is 0.02 x d1. This results in a maximum difference between the largest and smallest diameter corresponding with the table below. The pipe or fitting spigot needs to be "rounded" using clamps when the deformation is larger.

diameter d <sub>1</sub>	d <sub>1</sub> max - d <sub>1</sub> min (mm)
40	1.0
50	1.0
56	1.0
63	1.0
75	1.5
90	2.0
110	2.0
125	2.5
160	3.0
200	4.0
250	5.0
315	6.0

3. Welding more than once



4. Load on vertical pipe



#### **Butt-weld**

Butt-welding is a very economical and reliable jointing technique for making welded joints, requiring only butt-welding equipment. All pipes and fittings can be joined by this welding method. Fittings for which a k-dimension is shown in the product section, (pages 6-17), can be shortened by no more than this amount. Butt-welding is extremely suitable for prefabricating pipe sections and for making special fittings.



#### **Preparations**

The following guidelines are of importance • Clean the heating element before when making an accurate butt-weld:


- Establish a work space where the jointing can be done without being effected by major weather conditions.
- Check the equipment functions properly. Welding equipment used on site deserves special attention.
- The fittings and or pipes need to be aligned in the welding machine. Mis-alignment can be up to 10% of the wall thickness.

#### Maximum temperature variation heating element

- each jointing operation with a lintfree cloth and suitable cleaner (see instructions supplied with the welding machine).
- Cut the pipe and/or fitting with a pipe cutter to make the end square.
- Make sure that once the pipe and/or fitting ends have been machined, they do not get dirty. Do not touch them with your hands. The surface needs to be clear of oil, grease and dirt.
- Put the pipe parts into the welding machine to facilitate a firm hold during the jointing process.
- A digital thermometer can be used to check the temperature of the heating plate. The temperature should be checked at several points around the plate and should be between 200°C and 220°C. Maximum deviation between points is given in the table.







## Butt-weld process


The butt-welding of Marley HDPE operates according to the following steps: (The five steps below relate to the image on page 26).


#### 1. Machining the surface

Both sides should be machined until they run parallel. When the machining is finished, open the carriages (the plastic shavings must be continuous and uniform in both sides to weld). Take off the milling cutter.

Verify the alignment between the machined surfaces. Remove the plastic shaving. Do not touch or get any dirt on the machined surfaces.

> Without removing the oxygen layer a weld cannot be guaranteed.






on page 28.

pipe ends abruptly onto each other. The removal of the heating element needs to be done quickly to prevent the pipe ends from cooling down. The times for changing over can be found in the table

#### 2. Preheating under pressure

Press the two ends to be jointed gradually on to the heating element until a bead is created. The size of the bead is a good indication that the appropriate pressure and time is used. For pressure and bead size see the table on page 28.




26 MARLEY HDPE

total time welding process



#### 3. Heating up with less pressure


HDPE is a good insulator, therefore at this stage it is necessary that the correct heating depth of the pipe ends is obtained. Only a small amount of pressure 0.01 N/mm2 is required to maintain the contact of the pipe ends with the heating element. The heat will gradually spread through the pipe/fitting end. The size of the bead will increase a little. The time and pressure needed for this phase can be found in the table on page 28.



jointing areas and immediately make those

#### 5. Welding and cooling

After the jointing areas have made contact they should be joined with a gradual increase in pressure up to the specified value. Keep the specified welding pressure at a constant level during the cooling period. Do not cool artificially.




The welded components can be removed from the machine when 50% of the cooling period has elapsed, providing that this is done carefully, with no load or strain being placed on the joint. The joint must then be left undisturbed for the remainder of the cooling period.

#### HDPE Welding parameters

In this table the welding parameters can be found for Marley HDPE. The exact regulation of the welding machine depends on its mechanical resistance. The tables provided with the machine are to be used for regulating the machine.

Diameter d <sub>1</sub> mm	Wall thickness e mm	Preheating pressure / welding pressure (0,15 N/mm <sup>2</sup> ) F <sub>O</sub> /F <sub>L</sub> N	Heating pressure (0,01 N/mm²) F <sub>d</sub> N	Height welding bead mm	Heating time sec	Changeover time sec	Building-up pressure time sec	Cooling time min
*40	3.0	55	4	0.5	29	4	4	4
*50	3.0	70	5	0.5	30	4	4	4
56	3.0	75	5	0.5	30	4	4	4
*63	3.0	85	6	0.5	31	4	4	4
75	3.0	105	7	0.5	32	5	5	4
*90	3.5	145	10	0.5	35	5	5	4
110	4.2	210	14	0.5	42	5	5	6
*125	4.8	275	18	1.0	48	5	5	6
*125	3.9	225	15	0.5	39	5	5	5
160	6.2	450	30	1.0	62	6	6	9
110	3.4	175	12	0.5	35	5	5	4
160	4.9	370	25	1.0	49	5	5	7
200	6.2	570	38	1.0	62	6	6	9
250	7.8	900	60	1.5	77	6	6	11
315	9.7	1400	93	1.5	77	6	6	11
200	7.7	700	47	1.5	77	6	6	11
250	9.6	1090	73	1.5	97	7	7	13
315	12.1	1730	115	2.0	121	6	8	16

\*Please note these sizes are made to order and require a 28 day lead time.



## Installation videos

For further details on how to butt-weld or electrofusion joint the HDPE System go to the video section at marleypd.co.uk

## Evaluating the butt-weld

The butt-weld can be evaluated using destructive and non destructive evaluation methods. For these evaluations special equipment has to be used. Butt-welds can easily be judged by a visual inspection making this the recommended method for a first evaluation.

(acceptable)


as "acceptable".


The shape of the welding bead is an indication for the proper operation of the welding process. Both welding beads should have the same shape and size. The width of the welding bead should be approximately  $0.5 \times 10^{-5}$  x the height.

Differences between the beads can be caused by the difference in HDPE material used in the welded components. Despite the differences in welding bead the butt can be of sufficient strength.

#### Butt-weld with even welding beads (acceptable)

In the next illustration a good weld is shown with a uniform welding bead. At a visual inspection this would be classified as an "acceptable" weld.







#### Butt-weld with mis-alignment of pipe (acceptable)

Mis-alignment between fittings and pipe can occur for several reasons. Oval pipe ends or irregular necking of the pipe can cause an incomplete fit. If this is less than 10% of the wall thickness the weld can still be classified as "acceptable".

max 0.1 e\*





## 28 MARLEY HDPE



#### Butt-weld with big welding beads

The next illustration shows a joint with beads that are too big. The uniformity indicates a good joint preparation. Heat supply and jointing pressure settings, however, are too high. A purely visual assessment would still classify the weld



#### Butt-weld (not acceptable)

When there is either insufficient heating up or too low welding pressure there are hardly any beads. In cases like this thick



#### Cross section of a good butt-weld (acceptable)

In the next illustration a cross-section of a regular, round fusion bead, free of notches or sagging is shown. Special attention should be paid to the fact that the collar

#### Welding by hand

In general butt-welds are made using a butt-welding machine. However up to the diameter d1 = 75mm the weld can be made by hand. At 90mm and above the welding pressures are too big to make a good weld by hand. The welding process is identical to butt-welding with a machine:

#### 1. Preheating

Push the pipe/fittings against the heating plate until the required welding bead has been formed (see table on the previous page for further details).

#### 2. Heating up

Hold the pipe/fittings against the heating plate with no pressure (for time see table on the previous page).


#### 3. Change over/welding/cooling

As the spigots are thoroughly heated up, both parts need to be joined as quickly as possible using a gentle buildup of pressure. The jointing has to be carried out accurately because moving the parts during and after jointing is not possible.

Keep the parts jointed together under pressure as long as the welding bead is still plasticized (this can be checked by pressing your fingernail into the bead). The joint then needs to cool down without any additional load. The use of a support structure is recommended when jointing long pipe parts. Using a buttwelding machine gives a better result under all circumstances.

A: Plug-in joint socket A plug-in joint is an easy to make, detachable and non pull-tight jointing method.

Jointing process:



B: Expansion joint socket Expansion sockets can absorb length changes of pipes with a maximum length of 5m.



#### 1. Cut pipe square and remove burr



## 2. A Mark insertion depth

∖ ca. 15°

The pipe needs to be inserted in the plug in socket using the full insertion depth.

A plug-in joint is not to be used to accommodate the expansion and contraction of a pipe system.



An expansion socket counteracts the variation in length caused by the thermal expansion and shrinkage of the pipe.

Depending on the ambient temperature the insertion depth varies. The right insertion depth for both 0°C and 20°C is indicated on the expansion socket.

#### 3. Chamfer pipe end

The pipe-end needs to be chamfered at an angle of 15°. To obtain an even cut a chamfering tool should be used.

#### 4. Make joint

Lubricate the pipe end and insert the pipe up to the marked insertion depth.

HDPE	Expansion	Details

				Type A	Type B	
Diameter	Total Length	Min. Insertion Depth @ 20°C	Max. Expansion	(No white retaining ring)	(With white retaining ring)	
*40mm	132mm	76mm	56mm		Туре В	
*50mm	132mm	76mm	56mm		Туре В	
56mm	132mm	76mm	56mm		Туре В	
*63mm	132mm	76mm	56mm		Туре В	
75mm	-	On Fitting	On Fitting	Туре А		
*90mm	-	On Fitting	On Fitting	Туре А		
110mm	-	On Fitting	On Fitting	Туре А		
*125mm	-	On Fitting	On Fitting	Туре А		
160mm	-	On Fitting	On Fitting	Туре А		
200mm	230mm	120mm	110mm	Туре А		
250mm	250mm	125mm	125mm	Туре А		
315mm	270mm	126mm	144mm	Туре А		

\*Please note these sizes are made to order and require a 28 day lead time

# THE EXPERTS IN FABRICATED DRAINAGE

Save time on site by utilising the skills at Marley to build your bespoke fabricated soil system in the material of your choice







## Transitions to other materials


Transition to PVC and dBlue systems Transitions to metric PVC and dBlue systems can be made using a rubber ring joint or by screw couplers.	Marley HDPE	Marley PVC	Marley dBlue
Refer to the table on the right for	Fitting type	Diameter range (mm)	Code
the type of fittings, the dimensions	Plug-in socket	40-160	S 42 xx 50
and product code.	Snap socket	40-200	S 40 xx 10
The Marley HDPE range can be	Expansion socket	40-315	S 4x xx 20
connected to PVC-c or ABS materials, allowing for easy waste pipe connection to the discharge stack.	Screw coupler	40-110	S 43 xx 30

#### Bottle traps:


32mm and 40mm plug-in socket to bottle traps.










40mm HDPE



#### Alternative connectors:









## Transitions to other materials

#### Transition to metal thread

The transition from HDPE to metal thread requires screw thread adaptors available to order.

The adaptors are available with inside and outside thread in HDPE connection diameters 40, 50 and 63 mm. The adaptors have a cylindrical thread dimensioned according to DIN-ISO 288-1 with threads in 1/2", 3/4", 1", 11/4", 11/2", 2".

Speak to our Technical Services Department on 01622 852695 for a complete overview of product codes and available combinations.

#### Transition to cast iron

The transition from HDPE to cast iron requires special transition fittings to allow the change in outer diameter.



Available from Marley are transitions to cast iron in HDPE dimensions 200, 250 and 315 mm. Refer to the table below for the dimensions and product codes.

HDPE (mm)	Cast iron (mm)	Code
200	222	S 56 20 50
250	274	S 56 25 50
315	326	S 56 31 50

#### Transition to stoneware

The transition from HDPE to stoneware requires special transition fittings to allow the change in outer diameter.



Available from Marley are transitions to stoneware in HDPE dimensions 110 to 315 mm. Refer to the table below for the dimensions and product codes.

HDPE (mm)	Stoneware (mm)	Code
110	131	S 56 11 40
125	159	S 56 12 40
160	186	S 56 16 40
200	242	S 56 20 40
250	299	S 56 25 40
315	355	S 56 31 40

## Transition to plumbing

#### fixture fittings

Connections to plumbing are typically made to other materials, such as PVC, ABS, PP. Marley's HDPE adaptors can be seen on page 6. Marley also offer a range of traps and sanitary frames to complete the project

#### Transition to non standard diameters

Pipe connection with non-standard diameters can be connected to Marley HDPE using the Marley contraction sockets.



The contraction sockets have a variable connection diameter which shrinks and forms to the inserted pipe by applying heat. The connection is made watertight with a rubber ring and are available according to the table opposite.

#### 50 56 63 63 75 75 90 110 110 110 125 125 160 160 200 250

Diameter (mm)

40

40

50

## **Sanitary**


The Multikwik range includes sanitary frames, concealed cisterns and flush plates - all of the hidden things that offer reliability when designing modern washrooms.

For more information on the complete product range, visit the Multikwik website.



Connection diameter d <sub>x</sub> (mm)	Code
41-44	S 55 04 01
57-64	S 55 04 02
57-64	S 55 05 03*
67-74	S 55 05 04
62-69	S 55 56 01*
62-69	S 55 06 01
75-79	S 55 06 03
80-84	S 55 07 01*
90-94	S 55 07 02
94-98	S 55 09 02
102-111	S 55 11 02*
110-120	S 55 11 03
115-136	S 55 11 04
120-140	S 55 12 01
135-155	S 55 12 02
155-165	S 55 16 02
160-180	S 55 16 04
185-207	S 55 20 01
236-260	S 55 25 01

\*Products not in core range, but are available to order via Customer Services on 01622 852585



The HDPE soil system expands and contracts under influence of temperature changes. The pipe system therefore has to be installed correctly. This section describes the different pipe installation methods, bracket assembly methods and the correct bracket distances.

## Choice of pipe installation methods

The choice of the pipe fixing system is essential to correctly install the pipe system. Depending on the temperature of the medium, the ambient temperature and the building constraints there are the following options:

- 1. Free moving guide bracket system with axial movement correction by means of:
- a Expansion sockets
- b Deflection leq
- c Deflection leg with expansion socket

#### Guide bracket


The guide bracket is used to support the pipe and to prevent the pipe from buckling sideways when in a rigid installation. The pipe can freely move in the bracket.

#### Anchor bracket with expansion socket

This method of installation is used for flexible installations where the expansion force is not transferred to the building structure. Only the force caused by the internal resistance of the expansion socket is transferred.


#### Anchor point bracket

This method of bracketing is used for rigid installations. The expansion forces are transferred to the building structure. Within the Marley product range there are two options:



anchor bracket

- 2. Rigid anchor point bracket system 3. Embedding HDPE in concrete
- 4. Underground installation of HDPE



#### A. Bracket system with expansion sockets

The axial movement is caused by the linear Expansion and contraction expansion of the pipe. The total expansion  $\Delta$ I triggered by the temperature difference can be calculated using equation right or can be taken from graphic drawing at the bottom of the page.

calculation


 $\Delta I_t = L_{pipe} \cdot a_t \cdot t_{max} \cdot 10^3$ 

The maximum length change which can be accommodated by the expansion sockets can be found in table below

#### Length change with expansion sockets

d, (mm)	Code	Total length (mm)	Min. insertion depth 20°C (mm)	Max. expansion (mm)	Type A (No White Retaining Ring)	Type B (With White Retaining Ring)
40	S 40 04 20	132	76	56		Туре В
50	S 40 05 20	132	76	56		Туре В
56	S 40 56 20	132	76	56		Туре В
63	S 40 06 20	132	76	56		Туре В
75	S 42 07 20	256	32	146	Type A	
90	S 42 09 20	256	33	144	Type A	
110	S 42 11 20	256	35	141	Type A	
125	S 42 12 20	256	37	139	Type A	
160	S 42 16 20	256	40	143	Type A	
200	S 40 20 20	230	120	110	Type A	

#### Length change caused by temperature difference



36 MARLEY HDPE



- $\Delta I_{\star}$  = Length change (mm)
- $L_{\text{pipe}}$  = Total length of pipe (m)
- Length change caused by temperature difference
- $a_{t}$  = Linear expansion coefficient (mm/m°K)
- t\_\_\_\_ = Temperature difference in °C




Average linear expansion coefficier

HDPE expansion sockets can accommodate the expansion and contraction of max. 6m. This rule of thumb can be used when no further calculations are made. This general rule is only applicable with:

#### ∆ ≤ 37.5°C.

The number of expansion sockets can specifically be calculated by using equitation table on previous page.

#### Pipe section with expansion socket



## Example: Length pipe section $(L_2 + L_3 + L_4)$ : 18 m

Installation temperature: 5°C Temperature medium: +15°C / +75°C Temperature difference: 75-5 = 70°K Total expansion: 18 m x 0.18 mm/mK. 70K = 227 mm expansion length per


expansion coupler d110 = 141mm

In a pipe section of 110 mm diameter this results in 227/141 =  $^{-1.6}$  = 2 expansion sockets. Therefore, based upon the calculation only 2 expansion sockets are needed as opposed to the general rule of thumb (18/6 = 3 expansion sockets). By calculating the maximum expansion a more cost efficient installation can be made. With short term temperature differences, for example the emptying of a bathtub, a reduction factor of 0.5 can be applied to the temperature difference. In the example this would result in 0.5 x 227/141 = ~0.8 = 1 expansion socket.

The general rules can be applied for pipe lengths  $\leq$  5m in most drainage applications. With extreme high temperatures possibly in combination with a complex route the number of expansion sockets may need to be calculated.

#### Vertical installation

The bracketry distance for vertical installation is in general 1.5 times the distance of the horizontal bracketing. There is no separate bracket distance for immediately in front of the expansion socket because there is no sagging of the pipe and the insertion is always in line.



d <sub>1</sub>	L <sub>v</sub>
50	1,0 m
56	1,0 m
63	1,0 m
75	1,2 m
90	1,4 m
110	1,7 m
125	1,9 m
160	2,4 m
200	3,0 m
250	3,0 m
315	3,0 m

## Horizontal installation

The bracket directly in front of the expansion socket has a shorter bracket distance  $(L_A^*)$  This enables a better guidance into the expansion socket (see illustration below). The bracketing distances for this application can be found in table right. The maximum distance between 2 expansion sockets is 5m.

#### Homzonital Installation

Horizontal installation with expansion sockets without support trays

GB = guide bracket


FP = anchor point

 $L_{A}$  = bracket distance

L<sub>A</sub>\* = bracket distance before expansion socket

## Bracket distances for horizontal installation with expansion sockets without support trays


d,	L <sub>A</sub>	L <sub>A</sub> *
50	0.8 m	0.4 m
56	0.8 m	0.4 m
63	0.8 m	0.4 m
75	0.8 m	0.4 m
90	0.9 m	0.5 m
110	1.1 m	0.6 m
125	1.3 m	0.7 m
160	1.6 m	0.8 m
200	2.0 m	1.0 m
250	2.0 m	1.0 m
315	2.0 m	1.0 m



#### 1B. Guide bracket system with deflection leg

Deflection leg calculation

GB = guide bracket FP = anchor point LV = bracket distance



 $L_B$  = Length deflection leg L = Pipe length GB= Guide bracket  $\Delta I$  = Length change



#### Bracket distances vertical installation to the wall

For calculating the length of the deflection leg, the equation below can be used or graphic drawings on page 40 depending on temperature of installation and operation.

Calculating the length of deflection leg

 $L_{B} \ge 10 \text{ x } \sqrt{\Delta I} \text{ x } d_{1,2}$ 


 $L_{R}$  = Length of deflection leg (mm)

d<sub>1</sub> = Diameter pipe


 $\Delta I$  = Length change caused by expansion

First the length change  $\Delta I$  has to be determined at a temperature difference  $\Delta_{t_{max}}$  (see expansion and contraction calculation on page 37).

#### Length deflection leg at operating temperature 25°C-100°C



#### Length deflection leg at operation temperature -40°C-25°C




If the calculated deflection leg is shorter than the available length there will be no extra load on the pipe system. If this is not the case, an additional expansion socket needs to be installed (see section 1C on this page).

Fixing system

Check: Allowed  $L_A \leq L_{B1} + L_{B2}$ 

#### Check fixing system



d <sub>1</sub>	L <sub>A</sub>
50	0.8 m
56	0.8 m
63	0.8 m
75	0.8 m
90	0.9 m
110	1.1 m
125	1.3 m
160	1.6 m
200	2.0 m
250	2.0 m
315	2.0 m


#### 1C. Deflection leg calculation with expansion socket


When possible, a combination of a deflection leg with expansion sockets is recommended. It uses the advantages of both systems and saves expansion sockets. In the diagram right you will find an example of this.

## Installation with deflection leg and expansion sockets

GL


The expansion sockets take up the expansion of pipe sections  $L_3$  and  $L_4$ . Several quide brackets have to be installed. The deflection leg L<sub>R1</sub> and L<sub>R2</sub> compensates the length change of  $L_1$  and  $L_2$  from pipe section L<sub>1</sub> and L<sub>2</sub>. When the expansion is more than can be compensated in one expansion socket a number of expansion sockets with anchor brackets need to be used.







When the distance between both guide brackets is larger than the allowed bracket distance L<sub>a</sub>, the deflection leg needs additional support to prevent sagging. This extra bracket should not hinder the working of the deflection leg. This can be done by a pendulum bracket. Bracket distance  $L_A$  can be found in the table below.




## 2. Fixing system and thermal movement


#### Rigid anchor point bracket system

The bracket distances for Marley HDPE depends on the working temperature and the weight of the pipe including the medium. When the pipe is fully filled, other bracket distances are applicable (see graphic below).

#### Anchor point load at ambient temperature -40°C - 25°C



#### Anchor point load at ambient temperature >15°C



## 3. Embedding HDPE in concrete

#### Installation guidelines before pouring concrete

High density polyethylene (HDPE) is well suited to be embedded in concrete due to its physical characteristics and is guaranteed for this usage. Depending on the installation circumstances and materials used. certain installation practices are applied due to the maximum pipe strength and pipe expansion under influence of temperature changes.

HDPE pipe with s12.5 has a maximum

negative pressure of 450 mbar. When

the concrete is poured and is still liquid,

mbar. To compensate this, the pipe can

be filled with water and closed making

When quick drying concrete is used, the

exothermic reaction (a chemical reaction

that is accompanied by the release of

heat) can heat up the HDPE pipe and

degrade the material and lowering the

the concrete, the pipe system has to be

Because HDPE and hardened concrete do

secured against movement.

compensation

Expansion and contraction


allowed negative pressure. Before pouring

it an uncompressible closed system.

our class s16 pipe has a maximum


the outer pressure can exceed 800

allowed negative pressure of 800 mbar,




All 45° and 88.5° branches are subdued to the expansion force (FVP) which can be counteracted by installing a coupler. The coupler acts as an anchor point preventing the additional load to be transferred to the branch (see illustration below).

#### Anchor point with an electrofusion coupler



not adhere, the pipe system embedded in concrete can move freely when expanding under influence of temperature changes. All fittings installed in the pipe system act as an anchor point and are subdued to the expansion force. The concrete acts as a rigid system and the expansion and possible deformation of the fittings therefore has to be counteracted like in any HDPE installation.


When the length change of the HDPE is smaller than the shrinkage of the concrete no special precautions have to be taken however this is very rarely the case.







#### HDPE expansion forces in concrete Anchor point with expansion sockets



When the length of the branch is more than 2m. special precautions have to be taken as well. A fitting installed in a ceiling penetration acts as an anchor point as well. In case branches are used in a ceiling, it is recommended to use a coupler.

## 4. Underground installation of HDPE

Please see markings of pipes and fittings to indicate the permitted application area(s) for which they are intended:

- B: application area code for components intended for use above ground inside the building, or for components outside buildings fixed onto the wall;
- D: application code for the area under and within 1m from the building where the pipes and fittings are buried in ground and are connected to the underground drainage and sewerage system;

The load capacity of underground plastic

BD: application area code for components intended for use for both code B and code D application areas

#### Installation guidelines before installing HDPE underground

#### Soil and traffic loads

Due to specific properties such as flexibility and resistance to cold temperature (freezing), HDPE pipe systems are ideal for use in underground pipe lines. Buried pipes are exposed to various loads. It is, in effect, the stability of HDPE in withstanding these pressures that makes it possible to lay the pipes at substantial depth. The suitability depends on such factors as depth, groundwater level, density of the soil and traffic load.

pipes is based on changes in the pipe and movement of the ground. The soil load causes the top of the pipe to deflect downward. The sides of pipe are correspondingly pressed outward against the surrounding soil. The reaction pressure, the lateral force exercised on the pipe, prevents a larger cross-sectional deformation (support function). The construction of the trench, the type of bedding used and the backfilling of the trench are, to a large extent, decisive factors determining the load capacity of an underground plastic pipe. The load needs to be evenly distributed over the entire pipe line. For this reason, the trench must be created in such a manner that bends in a longitudinal direction and loads at specific points are avoided.

It is assumed that the increased pressure resulting from traffic loads caused by road or rail traffic are surface loads evenly distributed over the pipe sectional plane.

#### Groundwater

Underground pipes can be subject to external overpressure, especially in areas with high groundwater levels. In addition, a pipe enclosed in concrete is exposed to external pressure, though just for a short period.

#### Underground

Pipe systems subject to additional external pressure must be tested for the ability to withstand dinting. The effective load due to external pressure will agree with the related hydrostatic pressure on the pipe axis. For special circumstances, request assistance from our Technical Services department by calling 01622 852695.

#### Embedding of the pipe (consolidation) - zone 2

The fill for the pipe system embedding must consist of stone-free sand or similar material: the fill must ensure optimal compacting of the ground. The embedding is, to a large extent, a decisive factor in distributing the soil pressure and load, as well as providing lateral soil pressure on the pipe with the resulting unburdening effect.

at least 100mm above any pipe fittings.

#### Filling of trench (protective layer) - zone 3

The trench is backfilled in layers and compacted. Types of soil and materials that can cause dents may not be used to backfill the trench (e.g. ash, waste, stones). The use of heavy compacting equipment to compact the soil is not permissible for soil layers <1,0 m. The required thickness of zone 3 depends on trench form and pipe-wall thickness. Our Technical Support department can advise you in this regard.


Due to the risk of the waste water freezing, the pipes must be laid at a frost-free depth.

#### Construction and installation of underground pipe systems

#### Trench base (bedding) - zone 1

The state and form of the trench base must match the mechanical properties of the thermoplastic pipe. The existing or newly constructed support layer must consist of stone-free sand that has been slightly compressed using a suitable piece of equipment. The pipe must be laid in such a way that a stable surface with at least a 90° arc of enclosure is created in order to prevent sagging or intermittent loads.

The trench in which the pipe is laid must be sufficiently narrow in order to keep the final soil pressure as low as possible. The space between pipe and trench wall must be at least 100mm.



The height of zone 1 depends on the soil conditions and the nominal pipe width, and is calculated using the following equation.

		DN
H <sub>so</sub> =	H <sub>m</sub> +	10

Hso = height of the soil in zone 1 (mm)

Hm = minimum initial thickness normal soil conditions: 100mm rocky or thick soil: 150 mm

DN = nominal pipe width (mm)


## Underground

Marley offers a wide range of Underground systems:


- Solid wall system
- Quantum Sewer
- Quantum Highway
- Large diameter Quantum Highway

For more information, visit marleypd.co.uk





The height of zone 2 must extend to at least 150 mm above the pipe. This must also be







## **Bracket distance**

The bracket distances for Marley HDPE pipes are largely dependent on the working temperature of the pipe system. Also the filling rate of the pipe plays a role. A fully filled pipe has a different bracket distance.


#### Bracket distances for vertical and horizontal HDPE pipe systems with standard filling



#### Bracket distances and weights for half filled and fully filled pipe systems at 20°C




1	Pipe half filled			Pipe fully filled		
Pip (m	Pipe d <sub>e</sub> Weight G (mm) (N/m)			Pipe d <sub>e</sub> (mm)	Weight G (N/m)	
4	0	6,0		40	12,0	
5	0	9,5	1	50	19,0	
5	6	12,0	1	56	24,0	
6	3	15,5	1	63	31,0	
7	5	22,0	1	75	44,0	
9	0	31,5	1	90	63,0	
11	0	47,0	1	110	94,0	
12	25	61,0	1	125	122,0	
16	50	99,5	1	160	199,0	
20	00	156,0	1	200	312,0	
2	50	243,5	1	250	487,0	
3	15	387,0	1	315	774,0	







## Bracket drop distances



The below drop distances are provided as a guide, specific drop distances should be sourced from a suitable supplier who can verify the specific requirements for a particular application or project ensuring drop distances that are to be used are fit-for-purpose.


	Pipe diameter d <sub>1</sub>							
Distance to wall/ floor								
L (mm)	50	56	63	75	90	110	125	160
100	1/2"	1/2"	3/4"	3/4"	1"	1"	1 1/4"	1 1/2″
150	3/4"	3/4″	1"	1"	1"	1 1/4"	1 1/4″	2″
200	3/4"	3/4″	1"	1"	1 1/4"	1 1/2″	11/2″	2″
250	1″	1″	1″	1″	1 1/4"	1 1/2″	2″	_
300	1″	1″	1 1/4"	1 <sup>1</sup> /4"	11⁄4″	2″	2″	-
350	11⁄4″	11⁄4″	1 1/4"	1 <sup>1</sup> /4"	1 1/2″	2″	2″	_
400	11⁄4″	11⁄4″	1 1/4"	1 <sup>1</sup> /4"	11⁄2″	2″	_	_
450	11⁄4″	11⁄4″	1 1/2″	1 <sup>1</sup> /2″	2″	2″	-	-
500	11⁄4"	11⁄4″	1 1/2″	1 <sup>1</sup> /2″	2″	_	_	_
550	11⁄4″	11⁄4″	1 1/2″	1 <sup>1</sup> /2″	2″	_	_	_
600	1 <sup>1</sup> /2″	1 1/2″	1 <sup>1</sup> /2″	11/2″	2″		_	_

When the pipe is larger than 160mm, a special construction is needed and has to be dimensioned.

## General bracketry guidance


#### Horizontal installation

Because the pipe generates different forces with different dimensions, the anchor brackets have to be placed at dimension changes, branches and on the beginning and end of a pipe section.



#### Vertical installation

The bracketing distance for vertical installation is in general 1.5 times the distance of the horizontal bracketing.




Bracket distances for horizontal and vertical installations with anchor brackets

d <sub>1</sub>	L <sub>A</sub>	L <sub>v</sub>
50	0.8 m	1.0 m
56	0.8 m	1.0 m
63	0.8 m	1.0 m
75	0.8 m	1.2 m
90	0.9 m	1.4 m
110	1.1 m	1.7 m
125	1.3 m	1.9 m
160	1.6 m	2.4 m
200	2.0 m	3.0 m
250	2.0 m	3.0 m
315	2.0 m	3.0 m



GB = guide bracket





 $FP = anchor point L_{A} = bracket distance$ 


MARLEY HDPE 49

# Typical installations

Typical single stack installation

with bracket distances S411195 Electrofusion coupling used as support above S701178 Anchor bracket with S709478 mounting plate ÷. 1700r Gap to accommodate thermal movement S231100 Access pipe S701110 Guide bracket with S709410 Mounting plate SM44W WC connector with with SA323W Cap & Seal SM43W Adjustable spigot bend SM41W WC manifold branch ± S421120 Expansion socket IU 101 S201156 56mm boss pipe butt-welded to S425650 Plug in socket \_ 600mn 800mm SE40 S251111 Branch butt-welded to S421150 Plug in socket SM43W CUT @ SM43W CUT @ SM43W CUT @ Access cap 60°  $\bigcirc$  $\bigcirc$ Ο 110mm SL403 PVC pipe min fall 18mm/m or 1:55 \_SB41 Bend 87.5° 2No S121145 Bends Bends 45° with S411195 Electrofusion couplings 1100mm max centres 600mm max from anchor point S411195 Electrofusion coupling S421120 Expansion coup 110mm S101100 HDPE pipe min fall 18mm/m or 1:80 2No S121146 Long spigot bend 45° 2No S701110 Guide brackets with S709410 Mounting plates S701178 Anchor bracket with S709478 Mounting plate 2No S701178 Anchor brackets with S709478 Mounting plates 450mm Min for single dwellings up to 3 stories in height 750mm Min for multi-storey buildings More than 5 stories no connctions allowed at first floor level

Typical secondary vented stack installation with bracket distances





## Appendix

#### Chemical resistance

The chemical resistance of HDPE is depicted per medium at a number of different temperatures. In general we can define the resistance as follows:

For standard soil and waste systems the resistance of HDPE is perfect. In these pipes systems hardly ever aggressive fluids are drained. When transporting chemical waste waters, the following factors have to be taken in account:

- medium
- concentration of this medium
- duration of exposure

- temperature

- volume

The chemical resistance list of the electrometric seals is to aid in establishing the suitability of a certain seal. This is only an indication of its suitability. The chemical deterioration of the polymer chain can lead to changes in the mechanical characteristics like tensile strength and elongation at break etc. The data is valid for a temperature of 20°C. At higher temperatures or longer duration of exposure a more aggressive condition can occur which shortens the lifespan of the seal.

#### Used symbols

#### HDPE pipe and fittings:

+

а

2

3

4

HDPE

NBR

EPDM

FPM

SBR

TPE

- Resistant, based on the test carried out I.
- Suitable material for this application.
- Limited resistance, further research necessary.
- No resistance.

#### Elastomeric seals:

- Little or no effect, volume change <10%. In heavy conditions this elastomere can show a small increase in volume and /or loss of physical properties.
- Possible change of physical properties, volume change 10%-20%, the elastomere can show increase in volume and a change in physical properties but can be suitable for static applications.
- Noticeable change of physical properties, large change in volume, and physical properties.
  - Elastomeric seal is not suitable. Influence too much.

#### Abbreviations:

Comm. Comp.= Commercial composition

= High	density	polyethylene

- = Acryl nitrile-butadiene rubber
- = Ethylene propylene copolymer
- = Vinylidene fluoride copolymer
- = Styrol butadiene rubber
- = Thermoplastic elastomer

Component Name	Formula	Remark	Concentration	Pipe	and fit HDPE °C	tings	NBR	astome EPDM	ric seals FPM °C	s SBR °C
Name	Formula			20	°С 40	60	°C 20	°C 20	°C 20	°C 20
Acetaldehyde	CH <sub>3</sub> CHO	Aqueous solution	40%	+	+		4	2	4	3
Acetaldehyde	CH <sub>3</sub> CHO	Technically pure	100%	+	1		4	2	4	3
Acetic Acid	CH3COOH	Aqueous solution	10%	+	+	+	4	3/4	4	4
Acetic Acid	CH3COOH	Aqueous solution	30%	+	+	+	4	4	4	4
Acetic Acid	CH3COOH	Aqueous solution	60%	+	+	+	4	4	4	4
Acetic Acid	CH3COOH	Aqueous solution	80%	1	1	-	4	4	4	4
Acetic Acid	CH <sub>3</sub> COOH	Technically pure	100%	+	+		4	4	4	4
Acetic Acid Anhydride	(CH <sub>3</sub> CO) <sub>2</sub> O	Technically pure	100%	+	1		4	2	4	2
Acetone	CH <sub>3</sub> COCH <sub>3</sub>	Aqueous solution	10%	+	+	+	4	1	4	2/3
Acetone	CH <sub>3</sub> COCH <sub>3</sub>	Technically pure	100%	1	1		4	1	4	2/4
Acetophenone	CH_COC_H_	Technically pure	Indetermined	+	+	+	4	1	4	4
Acrylonitrile Adipic Acid	CH <sub>2</sub> =CH-CN	Technically pure	100% Saturated	+	+	+ +	4	4	4	3
Alcohol	HOOC(CH <sub>2</sub> ) <sub>4</sub> COOH	Aqueous solution	40%	+	Ŧ	Ŧ	1	I	I	1
Alcoholic Spirits			Comm. Comp.	+	+					
Allyl Alcohol		Aqueous solution	96%	+	+	+				
Allyr Alcohol	$CH_2 = CH - CH_2OH$ $AI_2(SO_4)_3K_2SO_4_4H_2O$	Aqueous solution	Solution	+	+	+ +	2	1	1	1
Alum	$Al_{2}(SO_{4})_{3}K_{2}SO_{4}AH_{2}O$ $Al_{2}(SO_{4})_{3}K_{2}SO_{4}AH_{2}O$	Aqueous solution	Saturated	+	+	+	2	1	1	1
Aluminium Acetate	$(CH_2COO)_2AI$	Aqueous solution	Saturated	+	+	+	2	1	4	4
Aluminium Bromide	AlBr.	Aqueous solution	Saturated	+	+	+	1	1	1	1
Aluminium Chloride	AICI	Aqueous solution	All	+	+	+	2	1	1	1
Aluminium Fluoride	AIF <sub>3</sub>	Aqueous solution	Saturated	+	+	+	2	1	1	1
Aluminium Nitrate	Al(NO <sub>3</sub> ) <sub>3</sub>	Aqueous solution	Saturated	+			1	1	1	1
Aluminium Sulfate	$Al_2(SO_4)_3$	Aqueous solution	10%	+	+	+	2	1	1	1
Aluminium Sulfate	$Al_2(SO_4)_3$	Aqueous solution	Saturated	+	+	+	2	1	1	1
Ammonia	NH <sub>2</sub>	Aqueous solution	Solution	+	+	+	2	1	3	2
Ammonia Gas	NH <sub>3</sub>	Aqueous solution	Saturated	+	+	+	2	1	3	2
Ammonia Gas	NH <sub>2</sub>	Technically pure	100%	+	+	+	2	1	3	2
Ammonium Acetate	CH,COONH,	Aqueous solution	Saturated	+	+	+	-		5	_
Ammonium Bifluoride	NH <sub>4</sub> FHF	Aqueous solution	Saturated	+	+	+				
Ammonium Carbonate	(NH <sub>4</sub> ) <sub>2</sub> CO <sub>2</sub>	Aqueous solution	100%	+	+	+	2	1	2	2
Ammonium Chloride	NH <sub>4</sub> Cl	Aqueous solution	Saturated	+	+	+	1	1	1	1
Ammonium Fluoride	NH	Aqueous solution	25%	+	+	+	1	1	1	1
Ammonium Fosfate	(NH <sub>4</sub> ) <sub>3</sub> PO <sub>4</sub> X H <sub>2</sub> O		All	+	+	+	1	1	1	1
Ammonium Hydroxide	NH <sub>4</sub> OH	Aqueous solution	Solution	+	+	+	4	1	2	4
Ammonium Hydroxide	NH <sub>4</sub> OH	Aqueous solution	Saturated	+	+	+	4	1	2	4
Ammonium Nitrate	NH <sub>4</sub> NO <sub>3</sub>	Aqueous solution	Saturated	+	+	/	2	1	1	1
Ammonium Sulfate	$(NH_4)_2SO_4$	Aqueous solution	All	+	+	+	1	1	1	1
Ammonium Sulfhydrate	NH <sub>4</sub> OH(NH <sub>4</sub> ) <sub>2</sub> SO <sub>4</sub>	Aqueous solution	Solution	+						
Ammonium Sulfhydrate	NH <sub>4</sub> OH(NH <sub>4</sub> ) <sub>2</sub> SO <sub>3</sub>	Aqueous solution	Saturated	+						
Ammonium Sulfide	$(NH_4)_2S$	Aqueous solution	10%	+	+	+	1	1	1	1
Ammonium Sulfide	$(NH_4)_2S$	Aqueous solution	Saturated	+	+	+	1	1	1	1
Amyl Acetate	CH <sub>3</sub> COO(CH <sub>2</sub> ) <sub>4</sub> CH <sub>3</sub>	Technically pure	100%	+	+	+	4	2	4	3
Amyl Alcohol	CH <sub>3</sub> (CH <sub>2</sub> ) <sub>3</sub> CH <sub>2</sub> OH		100%	+	+		2	2	2	1
Amyl Chloride	CH <sub>3</sub> (CH <sub>2</sub> ) <sub>4</sub> Cl	Technically pure	100%	•			4	1	4	4
Aniline	C <sub>6</sub> H <sub>5</sub> NH <sub>2</sub>	Technically pure	100%	1			4	2/3	1	3
Aniline Chlorhydrate	C <sub>6</sub> H <sub>5</sub> NH <sub>2</sub> HCl	Aqueous solution	Saturated	1	1		2	2	1	1
Anthraquinone Sulfonic			Solution	+						
Acid	shall	Aquocus estation	009/				1	1	1	1
Antimony Trichloride	SbCl <sub>3</sub>	Aqueous solution	90%	+	+	+	1	1	1	1
Aqua Regia Arsenic Acid	3HCI+1HNO3		100% Saturated	-+	-+	-	4	4	2/3	4
Barium Carbonate	H <sub>3</sub> AsO <sub>4</sub>	Aqueous colution	All	+	+	+				
Barium Carbonate Barium Chloride	BaCO <sub>3</sub>	Aqueous solution Aqueous solution	All	+	++	+ +	1	1	1	1
Barium Hydroxide	BaCl <sub>2</sub> Ba(OH) <sub>2</sub>	Aqueous solution	Saturated	+	+	+	1	1	1	1
Barium Nitrate	12	Aqueous solution	Saturated	+	+	+ +	1		1	1
Barium Sulfate	Ba(NO <sub>3</sub> ) <sub>2</sub> BaSO <sub>4</sub>	Aqueous solution	Saturated	+	+	+	1	1	1	1
Barium Sulfide	BaS	Aqueous solution	Saturated	+	+	+	1	1	1	2
Beer	503	riqueous solution	100%	+	+	+	1	1	1	1
Benzaldehyde	C <sub>6</sub> H <sub>5</sub> CHO	Aqueous solution	Saturated	+	+	+	4	2	4	3
Benzene	C <sub>6</sub> H <sub>6</sub>	Technically pure	100%	I	-	-	4	4	3	4
Benzene + Benzine	-6 6	.comically pare	20/80%	1	-	-	2/3	4	2	4
	1	1		1			_,_	·	-	· ·



Component Name	Formula	Remark	Concentration		and fitt HDPE °C		NBR °C	lastome EPDM °C	FPM °C	SBF °C
				20	40	60	20	20	20	20
enzene Sulfonic Acid	C <sub>6</sub> H <sub>5</sub> SO <sub>3</sub> H	Aqueous solution	10%	-	4	4	1	4		
Senzine (Free Of Pb And	$C_5H_{12} \div C_{12}H_{26}$		100%	+	+	/	4	4	1	4
Aromatic)	C 11 CO 011	A	Caturated				4	4	1	4
Senzoic Acid	C <sub>6</sub> H <sub>5</sub> COOH	Aqueous solution	Saturated	+	+	+	4	4	1	4
Benzyl Alcohol	C <sub>6</sub> H <sub>5</sub> CH <sub>2</sub> OH	Technically pure	100%	+	+	1	4	1	1	4
Bleaching Lye	NaClO+NaCl	12,5%	Cl	1	1		4	1	1	4
Borax	Na2B <sub>4</sub> O <sub>7</sub>	Aqueous solution	All	+	+	+	1	1	1	1
Boric Acid	H <sub>3</sub> BO <sub>3</sub>	Aqueous solution	Saturated	+	+	+	1	1	1	1
Brine			Comm. Comp.	+						
Bromic Acid	HBrO <sub>3</sub>	10%	+	+	+		4	1	1	4
Bromine, Liquid	Br <sub>2</sub>	Technically pure	100%	-			4	3	2	4
Bromine, Liquid	Br <sub>2</sub>	-	High	-			4	4	1	4
Butadiene	CH <sub>2</sub> =CH-CH=CH <sub>2</sub>	Gas	100%	+			3	4	2	4
utane Gas	CH <sub>3</sub> CH <sub>2</sub> CH <sub>2</sub> CH <sub>3</sub>	100%	+	+	+		2	4	2	4
Butanediol	OHCH2CH2CH2CH2OH	Aqueous solution	10%	+	+	+				
utanediol	OHCH2CH2CH2CH2OH	Aqueous solution	Concentrated	1	-	-				
utyl Acetate	CH3COOCH2CH2CH2CH3	Technically pure	100%	1	1	/	4	2	4	4
utyl Alcohol	CH <sub>3</sub> (CH <sub>2</sub> ) <sub>3</sub> OH	Technically pure	100%	+	+	+	1	2	1	1
Butyl Ether	(CH <sub>3</sub> (CH <sub>2</sub> ) <sub>3</sub> )20	Technically pure	100%	1	-	-	4	3	4	4
utyl Phenol	C4H9C6H4OH	Technically pure	100%	-			4	4	2	4
Butyl Phthalate	HOOCC <sub>6</sub> H <sub>4</sub> COOC <sub>4</sub> H <sub>9</sub>	Technically pure	100%	+	1	/				
Butylene	CH <sub>2</sub> =CH-CH <sub>2</sub> CH <sub>4</sub>	Liquid	100%	-			2	4	1	4
Butylene Glycol	OHCH,-CH=CH-CH,OH	Technically pure	100%	+	+	+	1	1	1	1
Butylene	CH,=CH-CH,CH,	Technically pure	100%	-			2	4	1	4
Sutyric Acid	CH,CH,CH,COOH	Aqueous solution	20%	+	+	1				
Sutyric Acid	CH,CH,CH,COOH	Technically pure	100%	+	+	1				
alcium Acetate	Ca(CH <sub>3</sub> COO) <sub>2</sub>	Aqueous solution	Saturated	+	+	+	2	1	4	4
Calcium Bisulfite	Ca(HSO <sub>3</sub> ) <sub>2</sub>	Aqueous solution	Saturated	+	+	+	2	1	2	2
Calcium Carbonate	CaCO <sub>2</sub>	Aqueous solution	All	+	+	+	1	1	1	1
Calcium Chlorate	Ca(ClO <sub>3</sub> ) <sub>2</sub>	Aqueous solution	Saturated	+	+	+	1	1	1	1
Calcium Chloride	CaCl <sub>2</sub>	Aqueous solution	All	+	+	+	1	1	1	1
Calcium Hydroxide	Ca(OH) <sub>2</sub>	Aqueous solution	All	+	+	+	1	1	1	1
Calcium Hypochloride	Ca(CIO) <sub>2</sub>	Aqueous solution	Saturated	+	+	+	4	1	1	4
Calcium Nitrate		Aqueous solution	50%	+	+	+	4	1	1	
	$Ca(NO_3)_2$			-	-		1	1	I	1
Calcium Sulfate	CaSO <sub>4</sub>	Aqueous solution	Saturated	+	+	+	1	1	1	2
Calcium Sulfide	CaS	Aqueous solution	Saturated	1	1	1	1	1	1	2
Camphor Oil			Comm. Comp.	-	-					
Carbon Dioxide	CO <sub>2</sub> +H <sub>2</sub> O	Aqueous solution	Indetermined	+	+	+	1	1	1	1
Carbon Dioxide	CO <sub>2</sub>	Gas	100%	+	+	+	1	1	1	1
Carbon Disulfide	CS <sub>2</sub>	Technically pure	100%	1	-	4	4	1	4	
Carbon Monoxid	CO	Gas	100%	+	+	+	2	2	1	2
Carbon Tetrachloride	CCl <sub>4</sub>	Technically pure	100%	-						
Carbonic Acid	H <sub>2</sub> CO <sub>3</sub>	Aqueous solution	Saturated	+	+	+				
hloramine	C <sub>6</sub> H <sub>5</sub> SO <sub>2</sub> NNaCl	Aqueous solution	Solution	+						
hloric Acid	HCIO <sub>3</sub>	Aqueous solution	20%	1						
hlorine	Cl <sub>2</sub>	Wet	All	1	-	4	3	1	4	
hlorine	Cl <sub>2</sub>	Gas	100%	1	1	-	4	2	4	4
Chlorine	Cl,	Technically pure	100%	-						
Chlorine Water	Cl <sub>2</sub> +H <sub>2</sub> O	Saturated	1	1						
hloro Benzene	C <sub>6</sub> H <sub>5</sub> Cl	Technically pure	100%	I	-	-				
Chloro Sulfonic Acid	HCISO,	Technically pure	100%	-	-	-				
hloroform	CHCl <sub>3</sub>	Technically pure	100%	-			4	4	2	4
hrome Alum	KCr(SO <sub>4</sub> ) <sub>2</sub>	Aqueous solution	Saturated	+	+	+			_	
Chrome Alum	$\operatorname{KCr}(\operatorname{SO}_4)_2$	Indetermined	+	+	+					
Chromic Acid	CrO <sub>3</sub> +H <sub>2</sub> O	Aqueous solution	10%	1	-	-	4	2/3	1	4
Chromic Acid	CrO <sub>3</sub> +H <sub>2</sub> O	Aqueous solution	30%	1	-	_	4	2/3	1	4
Chromic Acid	CrO <sub>3</sub> +H <sub>2</sub> O	Aqueous solution	50%	1	-	-	4	2/3	1	4
Citric Acid		Aqueous solution	50%	+	+	+	2	2/5	1	2
Compressed Air with Oil	$C_3H_4(OH)(COOH)_3$	riqueous solution	100%	+	+	т	2	1	I	2
•					-		2	1	4	A
Copper Acetate	Cu(COOCH <sub>3</sub> ) <sub>2</sub>	Aguagua - Luti-	Saturated	+			2	1	4	4
Copper Chloride	CuCl <sub>2</sub>	Aqueous solution	Saturated	+	+	+	1	1	1	1

Component Name	Formula	Remark	Concentration		and fit HDPE °C		NBR °C	EPDM °C	FPM °C	SBI °C
				20	40	60	20	20	20	20
Copper Nitrate	Cu(NO <sub>3</sub> ) <sub>2</sub>	Aqueous solution		+	+	+	2	1	1	1
Copper Sulfate	CuSO <sub>4</sub>	Aqueous solution		+	+	+	1	1	1	1
Copper Sulfate	CuSO <sub>4</sub>	Aqueous solution		+	+	+	1	1	1	1
Cresol	CH <sub>3</sub> C <sub>6</sub> H <sub>4</sub> OH	Aqueous solution		+	+					
Cresol	CH <sub>3</sub> C <sub>6</sub> H <sub>4</sub> OH	Aqueous solution	Solution	+	+					
Croton Aldehyde	CH <sub>3</sub> -CH=CH-CHO	Technically pure	100%	1						
Cryolite	Na_AIF_	Aqueous solution	Saturated	1	1	-				
Cyclohexane	C,H12	Technically pure	100%	+	+	+	2	4	1	4
Cyclohexanol	C, H110H	Technically pure	100%	+	1	1	2	4	2	3
Cyclohexanone	C <sub>6</sub> H <sub>10</sub> O	Technically pure	100%	+	1 I	1	4	3	4	4
Decalin Decahydronaftalene)	C <sub>10</sub> H <sub>18</sub>	Technically pure	100%	+	İ	1		-		
Detergents		Aqueous solution	Comm Comp	+	+	+				
Dextrine		Aqueous solution	Comm. Comp.	+	+	+				
	CIL O	Aqueous solution		+	+	+				
Dextrose	$C_6H_{12}O_6$									
Dextrose	C <sub>6</sub> H <sub>12</sub> O <sub>6</sub>	Aqueous solution		+	+	+				
Dextrose	C <sub>6</sub> H <sub>12</sub> O <sub>6</sub>	Aqueous solution	All	+	+	+	1	1	1	1
Dibutyl Phthalate	$C_6H_4(COOC_4H_9)_2$	Technically pure	100%	-			4	2	2	4
Dibutyl Sebacate	$C_{8}H_{16}(COOC_{4}H_{9})_{2}$	Technically pure	100%	+			4	2	2	4
Dichloro Benzene	C <sub>6</sub> H <sub>4</sub> Cl <sub>2</sub>	Technically pure	100%	1			4	4	2	4
Dichloroacetic Acid	CI, CHCOOH	Aqueous solution	50%	+	+	+	2	2	2	2
Dichloroacetic Acid	CI, CHCOOH	Technically pure	100%	+	+	1	3	2	3	3
Dichloroacetic Acid Methyl Ester	Cl <sub>2</sub> CHCOOH <sub>3</sub>	Technically pure	100%	+	+	+				
Dichloroethylene	CHCI=CHCI	Technically pure	100%	-				2	2	4
Diesel Oil		reennedity pure	100%	+	1	1	1	4	1	4
Diethylether	C,H_OC,H_	Technically pure	100%	-	-	1	4	4	4	4
,	HOOCCH_OCH_COOH		Saturated	+	-		4	4	4	4
Diglycolic Acid	<i>L</i>	Aqueous solution			,		4	2	4	21
Di-Isobutyl Ketone	(CH <sub>3</sub> ) <sub>2</sub> CHCH <sub>2</sub> COCH <sub>2</sub> CH(CH <sub>3</sub> ) <sub>2</sub>	Technically pure	100%	+	1	-	4	2	4	2/
Dimethyl Amine	(CH <sub>3</sub> ) <sub>2</sub> NH	Technically pure	100%		-					
Dimethyl Formamide	$HCON(CH_3)_2$	Technically pure	100%	+	+	/	4	2	4	3
Dioctyl Phthalate	$C_{6}H_{4}(COOC_{8}H_{17})_{2}$	Technically pure	100%	+			4	2	2	4
Dioxane	(CH <sub>2</sub> ) <sub>4</sub> O2	Technically pure	100%	+	+	+	4	2/3	4	4
Ethyl Acetate	CH <sub>3</sub> COOCH <sub>2</sub> CH <sub>3</sub>	Technically pure	100%	+	1	-	4	2/3	4	4
Ethyl Alcohol	CH <sub>3</sub> CH <sub>2</sub> OH	Aqueous solution	96%	+	+	/	2	1	2	1
Ethyl Benzene	C <sub>E</sub> H <sub>E</sub> C <sub>2</sub> H <sub>E</sub>	Technically pure	100%	1	1	1	4	4	2	4
Ethyl Chloride	CH, CH, CI	Technically pure	100%	Ì	-	2/3	4	2	4	
Ethyl Ether	CH,CH,OCH,CH,	Technically pure	100%	Ì	3	3	4	4		
Ethylene Chlorohydrin	CICH,CH,OH	Technically pure	100%	+	+	1	4	2	2	2
Ethylene Diamina	NH,CH,CH,NH,	Technically pure	100%	-	-	-	2	1	4	2
Ethylene Dichloride	CH,CICH,CI	Technically pure	100%	-	-	4	4	2/3	4	2
	2 2			+		+		1		1
Ethylene Glycol	HOCH <sub>2</sub> -CH <sub>2</sub> OH	Technically pure	100%		+	+	1	1	1	-
Ethylene Oxide	C <sub>2</sub> H <sub>4</sub> O	Technically pure	100%	-			3	3	4	4
Exhaust fumes			Traces	+	+	+				
Fatty Acids	R>C <sub>6</sub>	Technically pure	100%	+	+	/				
Ferric Chloride	FeCl <sub>3</sub>	Aqueous solution	Saturated	+	+	+	2	1	1	2
Ferric Nitrate	Fe(NO <sub>3</sub> ) <sub>3</sub>	Indetermined	+	+	+					
Ferric Sulfate	$Fe_2(SO_4)_3$	Aqueous solution	Saturated	+	+	+				
Ferrous Chloride	FeCl.,	Aqueous solution		+	+	+	2	1	1	2
Ferrous Nitrate	Fe(NO <sub>3</sub> ) <sub>2</sub>	Aqueous solution		+	+	+				
Ferrous Sulfate	FeSO,	Aqueous solution		+	+	+	2	1	1	2
Fertilizer Salts		Aqueous solution		+	+	+	_			-
Fertilizer Salts		Aqueous solution		+	+	+				
Fluoboric Acid	HBF	Technically pure	100%	+	+	+		1	1	1
	4	recrimically pure			Ŧ	+				
Fluorine Gas Dry	F <sub>2</sub>	A	100%	-	-			4	1	4
Fluosilicic Acid	H <sub>2</sub> SiF <sub>6</sub>	Aqueous solution		+	+	+				
Formaldehyde	CH <sub>2</sub> O	Aqueous solution		+	+	+	1	1	1	1
Formamide	HCONH <sub>2</sub>	Technically pure	100%	+	+	+	2	2	1	1
Formic Acid	HCOOH	Aqueous solution	50%	+	+	+	4	2	4	2
	НСООН	Technically pure	100%	+	+	+	4	2	4	2
Formic Acid	псоон	recrifically pure	10070				-	2		_



Component			Concentration	Pipe and fittings			El	astomer	ic seals	5
Name	Formula	Remark			HDPE °C		NBR °C	EPDM °C	FPM °C	SBR °C
		Keinerk		20	40	60	20	20	20	20
Furfuryl Alcohol	C <sub>5</sub> H <sub>6</sub> O <sub>2</sub>	Technically pure	100%	+	+	/	4	2		4
Gelatine	5 0 2		100%	+	+	+	1	1	1	1
Glycerine	C <sub>2</sub> H <sub>2</sub> (OH) <sub>2</sub>	Aqueous solution	All	+	+	+	1	1	2	1
Glycocoll	NH,CH,COOH	Aqueous solution	10%	+	+					
Glycolic Acid	HOCH,COOH	Aqueous solution	37%	+	+	+				
Gas containing:	2									
Carbon Dioxide	CO <sub>2</sub>	Gas	All	+	+	+				
Carbon Monoxid	CO	Gas	All	+	+	+				
Hydrochloric Acid	HCL	Gas	All	+	+	+				
Hydrochloric Acid	HCL	Gas	All	+	+	+				
Hydrofluoric Acid	HF	Gas	< 0,1%	+	+	+				
Nitrous Vapours	NO, NO <sub>2</sub> , N2O <sub>3</sub> , NOx	Gas	< 0,1%	+	+	+				
Nitrous Vapours	NO, NO <sub>2</sub> , N2O <sub>3</sub> , NOx	Gas	5%	+	+	+				
Oleum	$H_2SO_4 + SO_3$	Gas	< 0,1%	-	-	-				
Oleum	$H_2SO_4 + SO_3$	Gas	5%	-	-	-				
Sulphur Dioxide Liquid		Gas	All	+	+	+				
Sulphur Trioxide	SO <sub>3</sub>	Gas	< 0,1%	•	-	-				
Sulphuric Acid	H <sub>2</sub> SO <sub>4</sub>	Gas	All	+	+	+				
Heptane	C <sub>7</sub> H <sub>16</sub>	Technically pure	100%	+	Ι	-	1	4	1	4
Hexane	$C_{6}H_{14}$	Technically pure	100%	+	Ì	1	1	4	1	4
Hydrazine Hydrate	NH <sub>2</sub> -NH <sub>2</sub> H <sub>2</sub> O	Aqueous solution	Solution	+	+	+		2	1	1
Hydrobromic Acid	HBr		10%	+	+	+	3	2	1	3
Hydrobromic Acid	HBr		48%	+	+	+	4	1	1	4
, Hydrochloric Acid	HCI	Aqueous solution	10%	+	+	+				
Hydrochloric Acid	HCI	Aqueous solution	30%	+	+	+	2/3	1	2	2/3
Hydrochloric Acid	HCI	Aqueous solution	5%	+	+	+	-1-			=1=
Hydrochloric Acid	HCI	Aqueous solution	Saturated	+	+	+				
Hydrocyanic Acid	HCN	Aqueous solution	Solution	+	+	+	2	2	1	2
Hydrocyanic Acid	HCN	Technically pure		+	+	+	2	2	1	2
Hydrofluoric Acid	HF	Aqueous solution	10%	+	+	1	4	3	2/3	3
Hydrofluoric Acid	HF	Aqueous solution	40%	+	1	1	4	3	2/3	3
Hydrofluoric Acid	HF	Aqueous solution	70%	+	, I	1	4	3	2/3	3
Hydrogen Gas	H <sub>2</sub>		100%	+	+	+	2	1	1	4
Hydrogen Peroxide	H <sub>2</sub> O <sub>2</sub>	Aqueous solution	10%	+	+	+	2	1	1	2
Hydrogen Peroxide	H <sub>2</sub> O <sub>2</sub>	Aqueous solution	50%	+	+	1	2	1	1	2
Hydrogen Peroxide	H <sub>2</sub> O <sub>2</sub>	Aqueous solution	90%	+	-	-	2	1	1	2
Hydrogen Sulfide	H <sub>2</sub> S	Aqueous solution	Saturated	+	+	+	_			_
Hydrogen Sulfide	H <sub>2</sub> S	/iqueous solution	100%	+	+	1				
Hydroquinone	C <sub>2</sub> H <sub>4</sub> O <sub>2</sub>	Aqueous solution	Saturated	+	+	+	3	4	2	4
Hydroxylamine Sulphate	042	Aqueous solution	All	+	+	+	5		2	
odine Dry And Wet	12	Aqueous solution	3%	1	-		1	2	1	1
so-Octane	C <sub>8</sub> H <sub>18</sub>		100%	1	1	-	1	4	1	4
sopropyl Alcohol	$(CH_3)_2$ CHOH	Technically pure	100%	+	+	+	2	1	1	2
Isopropyl Ether	$(CH_3)_2$ CHOCH $(CH_3)_2$	Technically pure	100%	1	-	-	2/3	3	4	4
Lactic Acid	CH <sub>3</sub> / <sub>2</sub> CHOHCOOH	Aqueous solution	<=28%	+	+	+	2/5	1	1	3
Lanoline	CH <sub>3</sub> CHORCOOT	riqueous solution	Comm. Comp.	+	+	+	1	4	1	4
Lard Oil			Comm. Comp.	+				+	1	4
Lead Acetate	Pb(CH,COO),	Aqueous solution	Saturated	+	+	+	1	1	4	4
Lead Chloride	PbCl <sub>2</sub>	Aqueous solution	Saturated	+	+				+	4
Lead Nitrate	Pb(NO <sub>3</sub> ) <sub>2</sub>	Aqueous solution	Saturated	+			1	1	1	1
Lead Sulfate	PbSO <sub>4</sub>	Aqueous solution	Saturated	+	+	+	1	1	1	
inseed Oil	10004	riqueous solution	Comm. Comp.				1	3	1	4
ubricating Oils			Comm. Comp.	-			2	4	1	4
Lubricating Oils, Free Of			Comm. Comp.	+	+	1	1	4	1	4
Aromatic			comm. comp.	Ŧ	Ŧ	1		4	1	4
Magnesium Carbonate	MgCO <sub>2</sub>	Aqueous solution	All	+	+	+	1	1	1	1
Magnesium Chloride	MgCl <sub>2</sub>	Aqueous solution	Saturated	+	+	+	2	1	1	1
Magnesium Nitrate	Mg(NO <sub>3</sub> ) <sub>2</sub>	Aqueous solution	Indetermined	+	+	+	2			
Magnesium Sulfate	Mg(NO <sub>3</sub> ) <sub>2</sub>	riqueous solution	Saturated	+	+	+	2	1	1	1
Magnesium Sulfate	1vig304			++	++	+	1	1	1	4
Malze Oli Maleic Acid	HOOC-CH=CH-COOH	Aqueous solution	Comm. Comp. Saturated	++	++	+	1	1	1	4
	HUUU-CH-CH-CUUH	riqueous solution	Jacuidleu	Ŧ	т	т				

Component			Concentration	Pipe and fittings HDPE			E NBR	Elastome EPDM		ls   SBR
Name	Formula	Remark		20	°С 40	60	°C 20	°C 20	°C 20	°C 20
Sodium Bisulfite	NaHSO	Aqueous solution	100%	+	+	+	1	1	1	2
Sodium Bromate	NaBrO	Aqueous solution	All	+	1					
Sodium Bromide	NaBr	Aqueous solution	Saturated	+	+	+				
Sodium Carbonate (Soda)	Na <sub>2</sub> CO <sub>3</sub>	Aqueous solution	Saturated	+	+	+	2	1	1	1
Sodium Chlorate	NaClO	Aqueous solution	All	+	+	+	2/3	2	1	4
Sodium Chloride	NaCl	Aqueous solution	Solution	+	+	+	1	1	1	1
Sodium Chloride	NaCl	Aqueous solution	Saturated	+	+	+	1	1	1	1
Sodium Chromate	Na <sub>2</sub> CrO <sub>4</sub>	Aqueous solution	Solution	+						
Sodium Cyanide	NaCN	Aqueous solution	All	+	+	+	2	1	1	1
Sodium Disulphite	Na <sub>2</sub> S <sub>2</sub> O <sub>5</sub>	Aqueous solution	All	+			1	1	1	2
Sodium Ferrocyanide	Na_FeCN_	Aqueous solution	Saturated	+	+					
Sodium Fluoride	NaF	Aqueous solution	Saturated	+						
Sodium Hydroxide	NaOH	Aqueous solution	10%	+	+	+	3	1	2	2
Sodium Hydroxide	NaOH	Aqueous solution	30%	+	+	+	4	1	3	2
Sodium Hydroxide	NaOH	Aqueous solution	50%	+	+	+	1	1	3	2
Sodium Hypochlorite	NaClO	Aqueous solution	12,50%	1			4	1	1	4
Sodium Hypochlorite	NaClO	Aqueous solution	3%	+	-	1	4	1	1	4
Sodium Iodide Nal	Aqueous solution	riqueous solution	All	+	1	1	4	I	1	4
Sodium Metasilicate		Aquippus solution	<5%	+	+	+				
	Na <sub>2</sub> SiO <sub>3</sub>	Aqueous solution	<5% Saturated	++	++	+	1	1	1	1
Sodium Metasilicate	Na <sub>2</sub> SiO <sub>3</sub>	Aqueous solution		-						
Sodium Nitrate	NaNO <sub>3</sub>	Aqueous solution	Saturated	+	+	+	1	1	1	1
Sodium Nitrite	NaNO <sub>2</sub>	Aqueous solution	Saturated	+						
Sodium Oxalate	Na2C2O4	Aqueous solution	Saturated	+						
Sodium Perborate	NaBO <sub>3</sub>	Aqueous solution	All	+			2	1	1	2
Sodium Perchlorate	NaClO <sub>4</sub>	Aqueous solution	Indetermined	+						
Sodium Peroxide	Na <sub>2</sub> O <sub>2</sub>		Solution	+			2	1	1	2
Sodium Persulphate	Na <sub>2</sub> S <sub>2</sub> O <sub>8</sub>	Aqueous solution	Saturated	+	+	+				
Sodium Phosphate	Na <sub>3</sub> PO <sub>4</sub>	Aqueous solution	Saturated	+	+	+	1	1	1	1
Sodium Phosphate	Na, HPO	Aqueous solution	Saturated	+	+	1	1	1		
Monoacid	2 7									
Sodium Sulfate	Na <sub>2</sub> SO <sub>4</sub>	Aqueous solution	Saturated	+	+	+	1	1	1	1
Sodium Sulfide	Na <sub>2</sub> S	Aqueous solution	Solution	+	+	+	2	1	1	3
Sodium Sulfide	Na <sub>2</sub> S	Aqueous solution	Saturated	+	+	+	2	1	1	3
Sodium Sulfite	Na <sub>2</sub> SO <sub>3</sub>	Aqueous solution	Saturated	+	+	+				
Sodium Thiocyanate	NaSCN	Aqueous solution	Indetermined	+	+	+				
Sodium Thiosulphate	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub>	Aqueous solution	Saturated	+	+	+	3	1	1	2
Stannic Chloride	SnCl	Aqueous solution	Saturated	+	+	+	1	1	1	2
Stannous Chloride	SnCl	Aqueous solution	Saturated	+	+	+	1	1	1	1
Stearic Acid	C <sub>17</sub> H <sub>35</sub> COOH	Technically pure	100%	+	1		1	1	1	1
Styrene	C <sub>2</sub> H <sub>2</sub> CH=CH <sub>2</sub>	reennedity pare	100%	1	-	-	4	4	1	4
Sugar Syrup	6 <sup>115</sup> CIT CIT <sub>2</sub>		Saturated	+	+	+	1	1	1	1
Sulfamic Acid	HSO, NH,	Aqueous solution	20%	-					- 1	1
Sulphur	S	Aqueous solution	100%	+	+	+				
Sulphur Dioxide Liquid	-	Aqueous solution	Saturated	+	+	+	+			
	SO <sub>2</sub>				Ŧ	Ŧ	Ŧ			
Sulphur Dioxide Liquid	SO <sub>2</sub>	Technically pure	100%	-						
Sulphur Dioxide Liquid	SO <sub>2</sub>	Technically pure	100%	+	+	+	+			
Sulphur Trioxide	SO <sub>3</sub>	A	100%	-			2	-1	2	~
Sulphuric Acid	H2SO <sub>4</sub>	Aqueous solution	10%	+	+	+	2	1	2	2
Sulphuric Acid	H2SO <sub>4</sub>	Aqueous solution	50%	+	+	+	4	1	2	4
Sulphuric Acid	H2SO <sub>4</sub>	Aqueous solution	80%	+	+		4	2	2	4
Sulphuric Acid	H2SO <sub>4</sub>	Aqueous solution	90%		1	-				
Sulphuric Acid	H2SO <sub>4</sub>	Aqueous solution	96%	-	-	-	4	4	2	4
Sulphuric Acid	H2SO <sub>4</sub>	Aqueous solution indetermined	98%	-	-	-				
Sulphuric Acid	H2SO <sub>4</sub>	Technically pure	100%	-	-	-				
Sulphurous Acid	H2SO3	Aqueous solution	Saturated	+	+	+	2	2	1	2
Tallow Emulsion			Comm. Comp.	+	1	1	2	2	1	4
Tannic Acid	C <sub>76</sub> H <sub>52</sub> O <sub>46</sub>	Aqueous solution	All	+	+	+	2	2	2	2
Tartaric Acid	COOH(CHOH),COOH	Aqueous solution	All	+	+	+				
Tetrachloroethane	CHCl,CHCl,	100%	1	-			4	4	1	4
Tetrachloroethylene	Cl <sub>2</sub> C=CCl <sub>2</sub>	100%	1	-			4	4	2	4
	1 1		1		-	-	2	4		4



Component			Concentration	Pipe	and fit	and fittings		Elastomeric seals				
	Formula				HDPE		NBR	EPDM	FPM	SBR		
Name		Remark		20	°C 40	60	°C 20	°C 20	°C 20	°C 20		
Tetrahydrofurane	(CH <sub>2</sub> )4 <sub>0</sub>		100%	1		00	4	4	4	4		
Tetrahydronaphthalene			100%	1								
Thionyl Chloride	SOCI	Technically pure	100%	-			2/3	1	1	2/3		
Thiophene	C <sub>4</sub> H <sub>8</sub> S	100%	1	1	1		4	4	4	4		
Toluene	C <sub>2</sub> H <sub>2</sub> CH <sub>2</sub>	Technically pure	100%	1	-	-	4	4	2	4		
Toluic Acid	CH <sub>2</sub> C <sub>2</sub> H <sub>4</sub> COOH	reennedity pure	50%	1								
Transformer Oil	0.1.306.1.400011		Comm. Comp.	+	1	1		4	2	4		
Tributylphosphate	(C <sub>4</sub> H <sub>0</sub> ) <sub>3</sub> PO <sub>4</sub>	Technically pure	100%	+	+	+	4	2	3	4		
Trichlorethylene	CICH=CCI	Technically pure	100%	-	-	-	4	4	2	4		
Trichloroacetic Acid	CCI,COOH	Aqueous solution	50%	+	1	1	2	2	4	4		
Trichloroacetic Acid	CCI_COOH	Technically pure	100%	+	I	-	2	2	4	4		
Trichloroethane	CH,CCI,	Technically pure	100%	1	,		4	4	1	4		
Tricresylphosphate	(CH <sub>3</sub> C <sub>6</sub> H <sub>4</sub> O) <sub>3</sub> PO <sub>4</sub>	Technically pure	100%	+	+	+	4	2	2	4		
Triethanolamine	N(CH,CH,OH),	Technically pure	100%	+	+	1	3	1	4	2		
Trioctylphosphate	$(C_8H_{17})_3PO_4$	Technically pure	100%	1		/	4	1	2	4		
Turpentine Oil	(08, 17/3, 04	Technically pure	100%	í	-	-	2	4	1	4		
Urea	NH <sub>2</sub> CONH <sub>2</sub>	Aqueous solution	<=10%	+	+	+	1	1	1	1		
Urea	NH <sub>2</sub> CONH <sub>2</sub>	Aqueous solution	33%	+	+	+	1	1	1	1		
Urine Indetermined		riqueous solution	5576	+	+	+						
Vaseline Oil			Comm. Comp.	+	+	1		1	1	4		
Vegetable Oils and fats			Comm. Comp.	+	1	1	1	4	1	3		
Water	H <sub>2</sub> O		100%	+	+	+	1	1	1	1		
Water	H <sub>2</sub> O		100%	+	+	+	1	1	1	1		
Water	H <sub>2</sub> O		100%	+	+	+	1	1	1	1		
Water	H <sub>2</sub> 0		100%	+	+	+	2	1	2	2		
Water	H <sub>2</sub> O		100%	+	+	+	2	1	2	2		
Water, Rain	H <sub>2</sub> 0		100%	+	+	+	1	1	1	1		
Water, Salt	H <sub>2</sub> O+NaCl		Saturated	+	+	+	1	1	1	1		
Water, Sea			100%	+	+	+	1	1	1	1		
Wine			Comm. Comp.	+	+	+	1	1	1	1		
Wine Vinegar		Technically pure	Comm. Comp.	+	+	+						
Xylene	$C_{c}H_{4}(CH_{2})_{2}$	reality pare	100%	-	4	4	2	4				
Zinc Acetate	$Z_{n}(CH_{3}COO)_{2}$		Indetermined	+	+	+	2	1	4	4		
Zinc Chloride	ZnCl <sub>2</sub>	Aqueous solution	Solution	+	+	+	2	1	1	2		
Zinc Chloride	ZnCl <sub>2</sub>	Aqueous solution	Saturated	+	+	+	2	1	1	2		
Zinc Chromate	ZnCrO,	Aqueous solution	Indetermined	+	+	+	_			_		
Zinc Cyanide	$Zn(CN)_2$	Aqueous solution	All	+	+	+						
Zinc Nitrate	$Zn(NO_3)_2$	Aqueous solution	Indetermined	+	+	+						
Zinc Sulfate	ZnSO <sub>4</sub>	Aqueous solution	Solution	+	+	+	1	1	1	1		
Zinc Sulfate	ZnSO	Aqueous solution	Saturated	+	+	+	1	1	1	1		

The data is based on the latest knowledge. When in doubt please contact our Technical Support department.





# HDPE handling and storage

#### Pipes

The high impact strength of Marley HDPE provides some protection against damage but care should be taken at all stages of handling, transportation and storage.

Pipe must be transported by a suitable vehicle and properly loaded and unloaded, e.g. wherever possible moved by hand or mechanical lifting equipment. It must not be dragged across the ground. The storage should be flat, level and free from sharp stones.

#### Fittings

The fittings and electrofusion couplers need to be stored in a dry place. To prevent oxidation and contamination, it is recommended to leave the fittings in their original packaging as long as possible.

#### Testing the system

The system should be inspected for any possible leaks in accordance with BS EN 12056. Air should be pumped into the system through a branch of a tee piece until a pressure equal to 38mm water gauge is achieved. The inlet valve should then be closed and the system should maintain the pressure for a minimum of three minutes.


#### Tools

All tools must be protected against mositure, dust and should not be droppped.

HDPE pipe subjected to extensive periods of sun can cause pipe bowing, due to single sided heating. Shielding the pipe from direct sunlight will reduce this effect.

#### Storage

Bundled packs of pipe should be stored on clear, level ground with the battens supported from the outside by timber or concrete blocks. For safety, bundled packs should not be stacked more than three high.



Smaller pipes may be nested inside larger pipes. Side bracing should be provided to prevent stack collapse.

Similar precautions should be taken with fittings and these should be kept packaged until required for use.

#### Storage of loose pipes

Pipe lengths stored individually should be stacked in a pyramid not more that one metre high, with the bottom layer fully restrained by wedges. Where possible, the bottom layer of pipes should be laid on timber battens at one-metre centres. On site, pipes may be laid out individually in strings (where appropriate, protective barriers should be placed with adequate warning signs and lamps).

#### Storage of loose pipes



## Health and safety at work act and COSHH regulations

Attention is drawn to the requirement in the UK of this act and to the 1988 Control of Substances Hazardous to Health (COSHH) Regulations. Marley cannot accept responsibility for accidents arising from the misuse of its products because of bad installation or incorrect application.

Handling of HDPE has no detrimental health impact. It is recommended, however, that HDPE is not ingested or dust inhaled.

#### Personal Protective Equipment (PPE)

When welding HDPE, molten material is formed, which can cause burns to skin. Appropriate PPE should be worn.

#### Physical contact

HDPE is not considered to be a skin irritant. Where HDPE dust is generated by cutting of machining pipe of fittings, powder particles of HDPE dust may cause eye irritation by abrasion.

# THE TECHNICAL EXPERTS IN PLUMBING & DRAINAGE

## Our technical team can help you specify the system you need

Years of experience mean that we can support you throughout your design process and assist with any technical and installation requirements.









TECHNICAL ADVICE

CAD FILES

IN-AN TR/

IN-HOUSE AND EXTERNAL TRAINING



BIM OBJECTS



Ħ

ESTIMATES

## **Standards**

## **British & European Standards**

#### BS EN 1519-1: 2000

Plastics piping systems for soil and waste discharge (low and high temperature) within the building structure - polyethylene.

#### EN 12666

Plastics piping systems for non-pressure underground drainage and sewerage Polyethylene (PE) - Part 1: Specifications for pipes, fittings and the system.

#### EN 1053

Plastics piping systems. Thermoplastics piping systems for nonpressure applications. Test methods for water tightness.

#### EN 681

Elastomeric seals. Material requirements for pipe joint seals used in water and drainage applications.

#### BS EN ISO 9001: 2008

Quality systems. Model for Quality Assurance in Design, Development, Production, Installation and Servicing.

#### BS EN ISO 14001: 2004

Environmental management systems. Requirements with guidance for use.

## Accreditations





Customer attention is drawn to the Company's official Terms and Conditions of Sale. Goods are supplied strictly in accordance with these terms and conditions, copies of which are freely available on request and on marleypd.co.uk. Product illustrations may vary slightly depending on the type and size. Product images are for illustrative purposes only. Qty, refers to the pack quantity. Products can be purchased individually e & o e.



for multiple inlet connections.



Certified to BS EN 1519, the Marley HDPE system offers an alternative solution to cast iron. The combination of the excellent material properties of HDPE with homogenous welded joints provide greater installation

HDPE Soil




The Marley rainwater range comprises advanced Life4 technology, textured Foundry Finish, and profiles up to heavy industrial to make it the most comprehensive available.





Sanitary

cisterns deliver behind the wall reliability for wall hung toilets and basins. Glass, metal and plastic flush plates offer client choice for modern bathroom designs.













flexibility with a range of jointing options.



Solid wall for round the house drainage with a range of adoptable inspection chambers. Quantum structured wall with smooth bore



Used in conjunction with the acoustic pipe brackets, Marley dBlue is designed to reduce noise and acoustic vibrations to a level of 16dB at 4l/s, making it perfect for multi-occupancy developments.



Studor P.A.P.A. (Positive Air Pressure Attentuator) and Studor air admittance valves provide a complete active drainage ventilation system solution which is particularly suited to high-rise applications.



reusable with the use of the demounting tool.



Flowloc is a Vortex flow control unit, which is used as part of an attenuation scheme. It controls the rate at which water is discharged to a drainage system or watercourse.

# MARLEY SYSTEM SOLUTIONS



## marleypd.co.uk

For general enquiries and details of your nearest stockist please call the customer services department: Tel: 01622 852585 Email: customerservice@marleypd.co.uk

#### To place an order

For delivery to England & Wales Email: orders.lenham@marleypd.co.uk Fax: 01622 851111 For delivery to Scotland Email: orders.uddingston@marleypd.co.uk Fax: 01698 810307

For all estimate requests Email: estimates@marleypd.co.uk

For Technical advice please call 01622 852695

#### **Head Office**

Lenham, Maidstone Kent ME17 2DE Tel: 01622 858888 Fax: 01622 858725

Email: marketing@marleypd.co.uk

#### Scotland

Birkenshaw Industrial Estate Uddingston, Glasgow G71 5PA Tel: 01698 815231 Fax: 01698 810307

#### **Export Division**

Lenham, Maidstone Kent ME17 2DE England Tel: +44 (0)1622 858888 Fax: +44 (0)1622 850778

Email: export@marleypd.co.uk

